



**CAUTION:** This stabilized antenna system is designed to be used with transmit/receive equipment manufactured by others. Refer to the documentation supplied by the manufacturer which will describe potential hazards, including exposure to RF radiation, associated with the improper use of the transmit/receive equipment. Note that the transmit/receive equipment will operate independently of the stabilized antenna system. **Prior to work on the stabilized antenna system, the power to the transmit/receive system must be locked out and tagged.**

When the transmit/receive system is in operation, no one should be allowed **anywhere within the radiated beam** being emitted from the reflector.

**The ultimate responsibility for safety rests with the facility operator and the individuals who work on the system.**

**INSTALLATION AND OPERATION  
MANUAL FOR SEA TEL BROADBAND-AT-SEA  
TRANSMIT / RECEIVE SYSTEM  
MODEL: 2406-51**

Sea Tel, Inc.  
4030 Nelson Avenue  
Concord, CA 94520  
Tel: (925) 798-7979  
Fax: (925) 798-7986  
Email: [seatel@cobham.com](mailto:seatel@cobham.com)  
Web: [www.cobham.com/seatel](http://www.cobham.com/seatel)



Sea Tel Europe  
Unit 1, Orion Industrial Centre  
Wide Lane, Swaythling  
Southampton, UK S0 18 2HJ  
Tel: 44 (0)23 80 671155  
Fax: 44 (0)23 80 671166  
Email: [seatel@cobham.com](mailto:seatel@cobham.com)  
Web: [www.cobham.com/seatel](http://www.cobham.com/seatel)

*Sea Tel Inc doing business as Cobham SATCOM*

January 28, 2009

Document. No. 129375 Revision A



These commodities, technology or software were exported from the United States in accordance with the Export Administration Regulations. Diversion contrary to U.S. law is prohibited.



Sea Tel Marine Stabilized Antenna systems are manufactured in the United States of America.



Sea Tel is an ISO 9001:2000 registered company. Certificate Number 19.2867 was issued August 12, 2005. Sea Tel was originally registered on November 09, 1998.




The Series 06 Family of Marine Stabilized Antenna Pedestals with DAC-2202 Antenna Control Unit complies with the requirements of European Norms and European Standards EN 60945 (1997) and prETS 300 339 (1998-03). Sea Tel European Union Declaration of Conformity for this equipment is contained in this manual.

## Copyright Notice

**All Rights Reserved.** The information contained in this document is proprietary to Sea Tel, Inc.. This document may not be reproduced or distributed in any form without the consent of Sea Tel, Inc. The information in this document is subject to change without notice.

Copyright © 2009 Sea Tel, Inc is doing business as Cobham SATCOM.



**Sea Tel®**  
*Marine Stabilized Antenna Systems*  
**European Union Declaration of Conformity**  
**Marine Navigational Equipment**

**The EU Directives Covered by this Declaration:**

European Norms and European Standards EN 60945 (1997) and prETS 300 339 (1998-03).

**The Product Covered by this Declaration:**

Series 06 Family of Marine Stabilized Antenna Pedestals with DAC-2200 Antenna Control Unit.

**The Basis on which Conformity is being Declared:**

The product identified above complies with the requirements of the above EU Directives by meeting the following standards:

\* EN 60945 (1997) "Marine Navigational Equipment - General Requirements – Methods of Testing and Required Test Results":


- Conducted Emissions (Clause 9.1 & 9.2)
- Radiated Emissions (Clause 9.1 & 9.3)
- Conducted Low Frequency (Audio) Interference (Clause 10.1 & 10.2)
- Conducted Radio Frequency Interference (Clause 10.3) & IEC 1000-4-6 (1995)
- Radiated Radio Frequencies (Clause 10.4) & IEC 1000-4-3 (1995)
- Fast Transients on Signal/Control Lines (Clause 10.5) & IEC 1000-4-4 (1995)
- Surges on AC Power Lines (Clause 10.6) & IEC 1000-4-5 (1995)
- Power Supply Short-Term Variation (Clause 10.7)
- Power Supply Failure (Clause 10.8)
- Electrostatic Discharge (Clause 10.9) & IEC 1000-4-2 (1995)
- Compass Safe Distance (Clause 11.2, Measurement Only)

\* prETS 300 339 (1998-03) Electromagnetic compatibility and Radio spectrum Matters (ERM); General ElectroMagnetic Compatibility (EMC) for Radio Communications Equipment.

- RF Radiated Field Immunity (Clause 9.3)
- RF Common Mode Immunity (Clause 9.4, 9.5 & 9.6)

The technical documentation required to demonstrate that this product meets the requirements of the EMC Directive has been compiled by the signatory below and is available for inspection by the relevant enforcement authorities. The CE mark was first applied to this equipment in 2005.

Authority: Mr. J. Patrick Matthews  
President

Signature:   
Date: 7/27/05

**Attention**

The attention of the specifier, purchaser, installer or user is drawn to special measures and limitations to use which must be observed when the product is taken into service to maintain compliance with the above directives. Details of these special measures and limitations are in the product manual.

RF Transmit and Receive equipment components (Radio Packages, Drivers, HPAs and LNCs) or TVRO LNBs which are mounted on the Marine Stabilized Antenna Pedestal must be CE marked separately by the manufacturer of those components.



Sea Tel, Inc.  
4030 Nelson Ave.  
Concord, CA. 94520  
Phone: (925) 798-7979  
Fax: (925) 798-7986



Doc 124593-A

## Revision History

REV	ECO#	Date	Description	By
A	N/A	January 28, 2009	Production Release.	MDN

- 1. INTRODUCTION ..... 1-1**
  - 1.1. GENERAL SYSTEM DESCRIPTION ..... 1-1
  - 1.2. PURPOSE ..... 1-1
  - 1.3. SYSTEM COMPONENTS ..... 1-1
  - 1.4. GENERAL SCOPE OF THIS MANUAL ..... 1-1
  - 1.5. QUICK OVERVIEW OF CONTENTS ..... 1-2
- 2. OPERATION ..... 2-1**
  - 2.1. SYSTEM POWER-UP ..... 2-1
  - 2.2. ANTENNA INITIALIZATION ..... 2-1
  - 2.3. ANTENNA STABILIZATION ..... 2-1
  - 2.4. STABILIZED PEDESTAL ASSEMBLY OPERATION ..... 2-1
  - 2.5. TRACKING OPERATION ..... 2-1
  - 2.6. ANTENNA POLARIZATION OPERATION ..... 2-2
  - 2.7. LOW NOISE BLOCK CONVERTER OPERATION ..... 2-2
  - 2.8. RF EQUIPMENT ..... 2-2
  - 2.9. FCC TX MUTE FUNCTION ..... 2-2
  - 2.10. RADOME ASSEMBLY OPERATION ..... 2-2
- 3. BASIC SYSTEM INFORMATION ..... 3-1**
  - 3.1. SATELLITE BASICS ..... 3-1
    - 3.1.1. *Ku-Band Frequency (10.95-12.75GHz)* ..... 3-1
    - 3.1.2. *Signal level* ..... 3-2
    - 3.1.3. *Satellite Footprints* ..... 3-2
    - 3.1.4. *Satellite polarization* ..... 3-2
  - 3.2. ANTENNA BASICS ..... 3-2
    - 3.2.1. *Unlimited Azimuth* ..... 3-2
    - 3.2.2. *Elevation* ..... 3-3
    - 3.2.3. *Antenna Reflector/Feed Assembly* ..... 3-3
    - 3.2.4. *Antenna polarization* ..... 3-3
    - 3.2.5. *Fixed frequency, Dual or Tri-band LNBS* ..... 3-3
    - 3.2.6. *Stabilization* ..... 3-3
    - 3.2.7. *Search Pattern* ..... 3-3
    - 3.2.8. *Tracking Receiver – Single Channel Per Carrier Receiver* ..... 3-3
    - 3.2.9. *Tracking* ..... 3-4
  - 3.3. COMPONENTS OF THE SYSTEM CONFIGURATION ..... 3-4
    - 3.3.1. *Antenna ADE Assembly* ..... 3-4
    - 3.3.2. *Antenna Control Unit* ..... 3-4
    - 3.3.3. *Above Decks AC Power Supply* ..... 3-5
- 4. INSTALLATION ..... 4-1**
  - 4.1. UNPACKING AND INSPECTION ..... 4-1
  - 4.2. SITE SELECTION ABOARD SHIP ..... 4-1
  - 4.3. ASSEMBLY NOTES AND WARNINGS ..... 4-1
  - 4.4. INSTALLING THE ABOVE-DECKS EQUIPMENT (ADE) ..... 4-2
    - 4.4.1. *34" Radome Assembly* ..... 4-2
    - 4.4.2. *Antenna Pedestal Mechanical Checks* ..... 4-2
  - 4.5. CABLE INSTALLATION ..... 4-3
    - 4.5.1. *Shipboard Cable Installation* ..... 4-3
    - 4.5.2. *Cable Terminations In The Radome* ..... 4-3

- 4.6. BELOW DECKS EQUIPMENT..... 4-4
  - 4.6.1. Antenna Control Unit Connections..... 4-4
  - 4.6.2. Terminal Mounting Strip Connections..... 4-4
  - 4.6.3. Control Cable Connections..... 4-4
  - 4.6.4. NMEA GPS, Modem Lock & TX Inhibit Output Cable Connections..... 4-4
  - 4.6.5. Ships Gyro Compass Connections..... 4-4
  - 4.6.6. IF Cable Connections..... 4-4
  - 4.6.7. AGC Tracking Input Connections..... 4-4
- 4.7. BROADBAND CONNECTIONS BELOW DECKS..... 4-4
- 4.8. SET-UP & CONFIGURATION..... 4-4
- 5. SET-UP & CONFIGURATION..... 5-1**
  - 5.1. OPERATOR SETTINGS..... 5-1
  - 5.2. OPTIMIZING TARGETING..... 5-1
  - 5.3. OPTIMIZING AUTO-POLARIZATION TX/RX..... 5-1
  - 5.4. CALIBRATING RELATIVE ANTENNA POSITION (HOME FLAG OFFSET)..... 5-2
    - 5.4.1. To Calculate HFO:..... 5-2
    - 5.4.2. To Enter the HFO value:..... 5-4
  - 5.5. RADIATION HAZARD AND BLOCKAGE MAPPING (AZ LIMIT PARAMETERS)..... 5-4
  - 5.6. TX POLARITY SETUP..... 5-5
  - 5.7. TRACK DISP..... 5-5
  - 5.8. DEFAULT SETUP PARAMETERS..... 5-6
- 6. FUNCTIONAL TESTING..... 6-1**
  - 6.1. ACU / ANTENNA SYSTEM CHECK..... 6-1
  - 6.2. LATITUDE/LONGITUDE AUTO-UPDATE CHECK..... 6-1
  - 6.3. SHIP HEADING – GYRO COMPASS FOLLOWING CHECK..... 6-1
  - 6.4. AZIMUTH & ELEVATION DRIVE..... 6-1
  - 6.5. FOUR QUADRANT TRACKING TEST..... 6-1
  - 6.6. BLOCKAGE SIMULATION TEST..... 6-2
  - 6.7. TEST BROADBAND OPERATION..... 6-2
- 7. MAINTENANCE AND TROUBLESHOOTING..... 7-1**
  - 7.1. WARRANTY INFORMATION..... 7-1
  - 7.2. RECOMMENDED PREVENTIVE MAINTENANCE..... 7-1
    - 7.2.1. Check ACU Parameters..... 7-2
    - 7.2.2. Latitude/Longitude Auto-Update check..... 7-2
    - 7.2.3. Heading Following..... 7-2
    - 7.2.4. Azimuth & Elevation Drive..... 7-2
    - 7.2.5. Test Tracking..... 7-2
    - 7.2.6. Visual Inspection - Radome & Pedestal..... 7-2
    - 7.2.7. Mechanical Checks..... 7-2
    - 7.2.8. Check Balance..... 7-2
    - 7.2.9. Observe Antenna Initialization..... 7-2
  - 7.3. TROUBLESHOOTING..... 7-3
    - 7.3.1. Theory Of Stabilization Operation..... 7-3
    - 7.3.2. Series 06 TXRX Antenna Initialization..... 7-3
    - 7.3.3. Troubleshooting using DacRemP..... 7-4
    - 7.3.4. Antenna Loop Error Monitoring..... 7-4
    - 7.3.5. Reference Sensor Monitoring..... 7-6
    - 7.3.6. Open Loop Rate Sensor Monitoring..... 7-7

7.3.7.	<i>Open Loop Motor Test</i> .....	7-9
7.3.8.	<i>To Disable/Enable DishScan</i> .....	7-9
7.3.9.	<i>Satellite Reference Mode</i> .....	7-9
7.3.10.	<i>To Read/Decode an ACU Error Code 0008 (Pedestal Function Error):</i> .....	7-10
7.3.11.	<i>Remote GPS LAT/LON Position:</i> .....	7-12
7.4.	MAINTENANCE.....	7-13
7.4.1.	<i>Balancing the Antenna</i> .....	7-13
7.4.2.	<i>To Adjust Tilt:</i> .....	7-14
7.4.3.	<i>To Reset/Reinitialize the Antenna:</i> .....	7-15
7.5.	PEDESTAL CONTROL UNIT CONFIGURATION – SERIES 06.....	7-16
7.5.1.	<i>To configure the PCU:</i> .....	7-16
7.5.2.	<i>Model Configuration Numbers</i> .....	7-16
<b>8.</b>	<b>2406-51 TECHNICAL SPECIFICATIONS</b> .....	<b>8-1</b>
8.1.	ANTENNA REFLECTOR/FEED 2406.....	8-1
8.2.	RF EQUIPMENT.....	8-1
8.3.	PEDESTAL CONTROL UNIT.....	8-1
8.4.	STABILIZED ANTENNA PEDESTAL ASSEMBLY.....	8-2
8.5.	RADOME ASSEMBLY, 34".....	8-2
8.6.	UNLIMITED AZIMUTH MODEM/MULTIPLEXER (3 CHANNEL).....	8-3
8.7.	ADE PEDESTAL POWER REQUIREMENTS:.....	8-3
8.8.	ENVIRONMENTAL CONDITIONS (ABOVE DECKS EQUIPMENT).....	8-4
8.9.	BELOW DECKS EQUIPMENT.....	8-4
8.9.1.	<i>DAC-2202 Antenna Control Unit (ACU)</i> .....	8-4
8.9.2.	<i>Terminal Mounting Strip (TMS)</i> .....	8-4
8.9.3.	<i>Satellite Modem</i> .....	8-4
8.9.4.	<i>Router</i> .....	8-4
8.10.	CABLES.....	8-5
8.10.1.	<i>Antenna Control Cable (Provided from ACU-Base MUX)</i> .....	8-5
8.10.2.	<i>Antenna L-Band IF Coax Cables (Customer Furnished)</i> .....	8-5
8.10.3.	<i>AC Power Cable Above Decks (Customer Furnished)</i> .....	8-5
8.10.4.	<i>Gyro Compass Interface Cable (Customer Furnished)</i> .....	8-5
<b>9.</b>	<b>DRAWINGS</b> .....	<b>9-1</b>
9.1.	2406-51 KU-BAND MODEL SPECIFIC DRAWINGS.....	9-1
9.2.	2406 GENERAL DRAWINGS.....	9-1

This Page Intentionally Left Blank

## 1. Introduction

---



**WARNING:** *RF Radiation Hazard - This stabilized antenna system is designed to be used with transmit/receive equipment manufactured by others. Refer to the documentation supplied by the manufacturer which will describe potential hazards, including exposure to RF radiation, associated with the improper use of the transmit/receive equipment. Note that the transmit/receive equipment will operate independently of the stabilized antenna system.*

**The ultimate responsibility for safety rests with the facility operator and the individuals who work on the system.**

### 1.1. General System Description

Your system includes a fully stabilized antenna that has been designed and manufactured so as to be inherently reliable, easy to maintain, and simple to operate. The equipment essentially permits unattended operation except for start-ups or when changing to different transponders, or satellites.

### 1.2. Purpose

This shipboard Transmit-Receive (TXRX) system provides you with two-way satellite voice/data broadband communications while underway on an ocean-going vessel. This can be used to provide a wide variety of telephone, fax and high speed data applications. Your antenna system can transmit to and receive from any desired Ku-band satellite which has adequate signal coverage in your current geographic area. This input will be distributed to your satellite modem and then to all of your other below decks computer, fax and telephone equipment.

### 1.3. System Components

The 2406 TXRX system consists of two major groups of equipment; an above-decks group and a below-decks group. Each group is comprised of, but is not limited to, the items listed below. All equipment comprising the Above Decks is incorporated inside the radome assembly and is integrated into a single operational entity. For inputs, this system requires only an unobstructed line-of-sight view to the satellite, Gyro Compass input and AC electrical power.

For more information about these components, refer to the Basic System Information section of this manual.

#### A. Above-Decks Equipment (ADE) Group

1. Stabilized antenna pedestal
2. Antenna Reflector
3. Feed Assembly with LNB(s)
4. Ku-Band Solid State Block Up-Converter (SSPBUC)
5. Radome Assembly

#### B. Below-Decks Equipment Group

6. Antenna Control Unit
7. Splitter with desired number of outputs (one output to the ACU and one output to the Satellite Modem are required).
8. Satellite Modem and other below decks equipment required for the desired communications purposes.
9. Other below decks LAN and VOIP equipment
10. Ethernet and telephone cables

### 1.4. General scope of this manual

This manual describes the Sea Tel Series 06 Antenna (also called the Above Decks Equipment), its' operation and installation. Refer to the manual provided with your Antenna Control Unit for its' installation and operating instructions.

**1.5. *Quick Overview of contents***

The information in this manual is organized into chapters. Operation, basic system information, installation, setup, functional testing, maintenance, specifications and drawings relating to this Antenna are all contained in this manual

## 2. Operation

---

Operation of your system is accomplished from the DAC-2202 Antenna Control Unit (ACU). Refer to the operation section of the DAC-2202 Antenna Control Unit manual.

### 2.1. System Power-up

Turn the power switch on front panel of the Antenna Control Unit (ACU) and the breaker switch inside the Antenna Radome ON to energize both units.

### 2.2. Antenna Initialization

A functional operation check can be made on the antenna stabilization system by observing its behavior during the 4 phases of initialization.

Turn the pedestal power supply ON. The PCU will initialize the stabilized portion of the mass to be level with the horizon and at a prescribed Azimuth and Elevation angles. The antenna will go through the specific sequence of steps (listed below) to initialize the antenna. These phases initialize the level cage, elevation, cross-level and azimuth to predetermined starting positions.

Initialization is completed in the following phases, each phase must complete properly for the antenna to operate properly (post-initialization).

1. Level Cage is driven CCW, issuing extra steps to assure that the cage is all the way to the mechanical stop. Then the Level cage will be driven exactly 45.0 degrees CW.
2. Elevation axis activates - Input from the LV axis of the tilt sensor is used to drive the Elevation of the equipment frame to bring the tilt sensor LV axis to level (this results in the dish being at an elevation angle of 45.0 degrees).
3. Cross-Level axis activates - Input from the CL axis of the tilt sensor is used to drive Cross-Level of the equipment frame to bring the cross-level axis of the tilt sensor to level (this results in the tilt of the Cross-Level Beam being level).
4. Azimuth axis activates - Antenna drives in azimuth until the "Home Flag" signal is produced. This signal is produced by a Hall Effect sensor coming into close proximity to a Magnet mounted in the azimuth driven sprocket.

This completes the phases of initialization. At this time the antenna elevation should 45.0 degrees and Relative azimuth should be at be at home flag (magnet in the azimuth driven sprocket is at the hall sensor mounted in the PCU enclosure).

If any of these steps fail, or the Antenna Control Unit reports model number as "xx03" or "xx06" re-configure the PCU as described in section the Maintenance section of this manual. If initialization still fails, refer to the troubleshooting section of this manual.

### 2.3. Antenna Stabilization

After initialization has completed, real-time stabilization of the antenna is an automatic function of the PCU. Transmit Muting for FCC compliance requires current ACU & PCU software and proper connections between the Terminal Mounting Strip and the Satellite Modem. This feature operates automatically, no operator assistance is required.

### 2.4. Stabilized Pedestal Assembly Operation

Operation of the stabilized antenna Pedestal Control Unit (PCU) is accomplished remotely by the Antenna Control Unit (ACU). Refer to the Operation section of the Antenna Control Unit manual for more specific operation details. There are no other operating instructions applicable to the pedestal assembly by itself.

### 2.5. Tracking Operation

Tracking optimizes the antenna pointing, in very fine step increments, to maximize the level of the satellite signal being received. The mode of tracking used in this antenna is a variation of Conical Scanning called DishScan. Tracking is controlled by the ACU. You can toggle Tracking ON/OFF from the ACU.

DishScan continuously drives the antenna in a very small circular pattern at 60 RPM. The ACU evaluates the received signal throughout each rotation to determine where the strongest signal level is (Up, Right, Down or Left) and then issues the appropriate Azimuth and/or Elevation steps to move the antenna toward where stronger signal is. The pedestal cannot control tracking. Refer to the ACU manual for more Tracking information.

### ***2.6. Antenna Polarization Operation***

Linear feeds are equipped with a polarization motor and potentiometer feedback and are controlled from the Antenna Control Unit. Auto-Polarization mode is the default polarization mode of operation from the ACU. Polarization may be operated manually from the ACU for diagnostic or alignment purposes. Refer to the Antenna Control Unit manual for more operation information.

### ***2.7. Low Noise Block Converter Operation***

There are no operating instructions or controls applicable to the LNBs. The ACU provides DC power to the desired LNB via the coax rotary joint and the pedestal modem.

A Cross-Pol LNB is installed on the receive port of the feed assembly and its' output coax is routed to the pedestal modem (labeled "Cross-Pol"). A diplexer is installed in the TX waveguide between the BUC and the TX port of the feed assembly. A Co-Pol LNB is installed on the RX output of the diplexer and its' output coax is routed to the pedestal modem (labeled "Co-Pol"). The desired output to be sent below decks (Co-Pol or Cross-Pol) is selected by connecting the correct coax to the pedestal modem.

### ***2.8. RF Equipment***

The RF Equipment is not operated or controlled by the antenna pedestal or Antenna Control Unit. Refer to the vendor supplied manuals for the RF Equipment and Satellite Modem which were provided with your system.

### ***2.9. FCC TX Mute Function***

FCC TX Mute function provides a transmit inhibit, or mute, signal to the Satellite Modem to disable transmit whenever the antenna is blocked, searching, targeting, unwrapping, or is mispointed >0.5 degrees from peak satellite position. This functionality is provided by software in the ACU & PCU. Hardware wiring connection between the ACU Terminal Mounting Strip and the Satellite Modem and proper setup of the ACU "SYSTEM TYPE" parameter are also required for this function to operate properly.

After being properly installed and setup correctly the FCC TX Mute function operation is automatic, therefore, requires no operator intervention. Refer to the Installation and Setup chapters in this manual and in your Antenna Control Unit manual.

### ***2.10. Radome Assembly Operation***

When operating the system it is necessary that the radome access hatch (and/or side door) be closed and secured in place at all times. This prevents rain, salt water and wind from entering the radome. Water and excessive condensation promote rust & corrosion of the antenna pedestal. Wind gusts will disturb the antenna pointing.

There are no other operating instructions applicable to the radome assembly by itself.

### 3. Basic System Information

This section provides you with some basic information about your antenna system and other equipment within your system configuration.

#### 3.1. Satellite Basics

The satellites are in orbit at an altitude of 22,753.2 Statute Miles positioned directly above the equator. Their orbital velocity matches the Earth's rotational speed, therefore, each appears to remain at a fixed position in the sky (as viewed from your location).

The satellites are simply relay stations that are able to receive signals from one location on the globe and re-transmit them to a much larger area on the globe than a local antenna could do. Because of their high vantage point, they are able to cover an area that is larger than a continent.

Your antenna can be used with any of the Ku-Band (10.95-12.75GHz) satellites in this orbit that have a strong enough receive signal level in your location. Your antenna is capable of transmitting and receiving Linear signal polarization, but requires that you have the appropriate LNB installed for the specific frequency range of that satellite.

If you could see the satellites in their positions above the equator, they would appear to form an arc as shown here (as viewed from a position in the Northern Hemisphere). When you are on the same longitude as the satellite, its' horizontal and vertical signals will be purely aligned to your horizon. When the satellite is east or west of your longitude, the satellite signals will appear to be rotated clockwise or counter-clockwise from pure horizontal and vertical. Both horizontal and vertical signals from a satellite will appear to be rotated the same amount and are always perpendicular to each other. The amount of rotation is dependent on how far east or west the satellite is from you and how close you are to the Equator.




Figure 3-1 Arc of viewable Satellites

#### 3.1.1. Ku-Band Frequency (10.95-12.75GHz)

At these frequencies the signal from the satellite travels only in a straight line and is affected by weather changes in the atmosphere. There are several conditions that can cause a temporary loss of satellite signal, even within an area where the signal level is known to be adequate. The most common of these *normal* temporary losses are **blockage** and **rain fade**. They will normally interrupt services only as long as the cause of the loss persists.

**Blockage** - Blockage is loss due to an object in the path of the signal from the satellite to the dish. If an object that is large and dense is positioned in the path of the signal from the satellite, it will prevent sufficient signal from arriving at the dish. The signal can not bend around, or penetrate through, these objects. The reception will be degraded or completely interrupted until the object is no longer in the path of the signal to the dish. The dish is actively driven to remain pointed at the satellite (toward the equator) so, as the boat turns a mast or raised structure on the boat may become positioned between the satellite and the dish. Blockage may also be caused a person standing near the radome, tall mountains, buildings, bridges, cranes or other larger ships near your boat. Signal will be lost when the boat is housed inside an enclosure that the signal cannot penetrate, like a paint shed or a berth with a roof. Moving or rotating the boat to position the antenna where it has an unobstructed view to the desired satellite will restore the antennas ability to receive the satellite signal.

**Rain Fade** - Atmospheric conditions that may cause sufficient loss of signal level include rain, snow, heavy fog and some solar activities such as sun spots and solar flare activity. The most common of these is referred to as "rain fade". Rain drops in the atmosphere reduce the signal from the satellite. The heavier the rain, the greater the signal loss. When the amount of loss is high enough, the antenna will not be able to stay locked onto the satellite signal. Once the amount of rain has decreased sufficiently, the antenna will re-acquire the satellite signal. In strong signal areas, rain fall of about four inches per hour will cause complete loss of signal. In weaker signal areas, lighter rainfall might cause the signal to be lost.

### 3.1.2. Signal Level

The level of the receive signal on a point on the globe is dependant upon how powerful the transmission is and how wide the signal beam is coverage area is. Focusing the signal into a narrower beam concentrates its energy over a smaller geographic area, thereby increasing the signal level throughout that area of coverage. This makes it possible for you to use a smaller antenna size to receive that satellite signal. The antenna system must be geographically located in an area where the signal level from the satellite meets (or exceeds) the minimum satellite signal level required for your size of antenna (refer to the Specifications section of this manual) to provide suitable reception. This limits the number of satellites that can be used and the geographic areas where the ship can travel where the signal level is expected to be strong enough to continue providing uninterrupted reception. When traveling outside this minimum signal coverage area, it is normal for the system to experience an interruption in its ability to provide the desired satellite services until entering (or re-entering) an area of adequate signal level (refer to the satellite footprint information). Systems with larger diameter dish antennas can receive signal further out towards the fringe of a given satellites coverage area.

### 3.1.3. Satellite Footprints

The focused beam(s) from the satellites are normally aimed at the major land masses where there are large population centers. Footprint charts graphically display the signal level expected to be received in different geographic locations within the area of coverage. The signal will always be strongest in the center of the coverage area and weaker out toward the outer edges of the pattern. The coverage areas are intended to be a guide to reception, however, the actual coverage area and signal level and vary. Also the signal strength is affected by weather. Your satellite service provider can provide coverage maps specific to your area of operations for your data/voice applications.

### 3.1.4. Satellite polarization

The satellites you will be using transmit their signals in linear polarization mode (like a flat ribbon down from the satellite).

The feed assembly installed on your antenna is designed to be fitted with a linear LNB (to receive horizontal and vertical linear polarized satellite transmissions. A motor, which is controlled by the ACU (Auto or Manual polarization), adjusts the "polarization" angle of the LNB installed on the feed to optimize the alignment of the LNB to match the angle of the signal from the satellite. Auto-Polarization mode of the ACU normally will keep the polarization optimized for you. When you are on the same longitude as the satellite, its' horizontal and vertical signals will be purely aligned to your horizon. When the satellite is east or west of your longitude, the satellite signals will appear to be rotated clockwise or counter-clockwise from pure horizontal and vertical. Both horizontal and vertical signals from a satellite will appear to be rotated the same amount and are always perpendicular to each other. The amount of rotation is dependent on how far east or west the satellite is from you and how close you are to the Equator.

## 3.2. Antenna Basics

The satellite dish is mounted on a three jointed pedestal. As your boat rolls, pitches and turns in the water, these three joints move to keep the dish pointed at the satellite. The following information is provided to explain some of the basic functions of the antenna:

### 3.2.1. Unlimited Azimuth

Azimuth rotation of the antenna is unlimited (no mechanical stops). Azimuth drive, provided by the azimuth motor, is required during stabilization, searching and tracking operations of the antenna. When the ship turns, azimuth is driven in the opposite direction to remain pointed at the satellite. The actual azimuth pointing angle to the satellite is determined by your latitude & longitude and the longitude of the satellite. It is important to know that the antenna should be pointed (generally) toward the equator.

The azimuth angle to the satellite would be 180 degrees true (relative to true north) if the satellite is on the same longitude that you are on. If the satellite is east, or west, of your longitude the azimuth will be less than, or greater than 180 degrees respectively.

When checking for blockage you can visually look over the antenna radome toward the equator to see if any objects are in that sighted area. If you are not able to find any satellites it may also be useful to remove the radome hatch to visually see if the dish is aimed the correct direction (towards the equator).

### **3.2.2. Elevation**

In normal operation the elevation of the antenna will be between 00.0 (horizon) and 90.0 (zenith). The antenna can physically be rotated in elevation below horizon and beyond zenith to allow for ship motion. Elevation drive, provided by the elevation motor, is required during stabilization, searching and tracking operations of the antenna. The actual elevation pointing angle to the satellite is determined by your latitude & longitude and the longitude of the satellite. In general terms the elevation angle will be low when you are at a high latitudes and will increase as you get closer to the equator.

Additionally, from any given latitude, the elevation will be highest when the satellite is at the same longitude that you are on. If the satellite is east, or west, of your longitude the elevation angle will be lower.

### **3.2.3. Antenna Reflector/Feed Assembly**

Comprised of an aluminum reflector with a Cassegrain feed assembly. The feed assembly is fitted with a polarization motor and a potentiometer for position feedback required for linear signal operation. A variety of interchangeable LNB's may be easily fitted to the feed, allowing it to be fitted with the appropriate frequency range LNB for the desired Ku-Band satellite.

In addition to the real time stabilization of the polarity assembly by the PCU, the ACU automatically adjusts the polarization angle of the feed by remotely controlling the stepper motor, using the potentiometer feedback for Linear polarization position (Auto-Polarization mode).

### **3.2.4. Antenna polarization**

When you have a linear LNB installed the polarization needs to be periodically adjusted, Auto-Polarization will automatically accomplish this for you.

To adjust polarization UP the LNB (as viewed from the front side of the reflector) must rotate CCW and to adjust polarity DOWN the LNB must rotate CW.

Polarization adjustment to optimize Auto-Pol is required when initially setting up the system or after you have installed a different LNB (refer to the Maintenance Section of this manual).

### **3.2.5. Fixed frequency, Dual or Tri-band LNBs**

Your antenna can easily be fitted with a variety of LNBs. The LNB must match the frequency band of the desired satellite. The Dual-Band LNB is able to be electrically switched from low band to high band from the antenna control unit. The Tri-Band LNB is able to be electrically switched from low band to mid band to high band from the antenna control unit. You must also have the correct option file loaded into your satellite modem for the LNB you have installed, or the band you currently have selected, to be able to use a specific satellite and its' voice & data services.

### **3.2.6. Stabilization**

This Sea Tel antenna is stabilized in three axes of motion. Stabilization is the process of de-coupling the ships motion from the antenna. Simply put, this allows the antenna to remain pointed at the satellite while the boat turns, rolls or pitches under it. To accomplish this, the Pedestal Control Unit (PCU) on the antenna pedestal senses any motion of the antenna and immediately applies drive to the appropriate motor(s) to oppose the sensed motion. Azimuth (AZ), Elevation (EL) and Cross-Level (left-right tilt) are actively stabilized automatically by the PCU as part of its normal operation.

### **3.2.7. Search Pattern**

Whenever the desired satellite signal is lost (such as when the antenna is blocked), the Antenna Control Unit will automatically initiate a search to re-acquire the desired signal.

The search is conducted with alternate azimuth and elevation movements. The size and direction of the movements are increased and reversed every other time resulting in an expanding square pattern.

When the antenna finds the desired satellite signal, the ACU will automatically stop searching and begin Tracking the signal. Tracking optimizes the pointing of the antenna to get the highest signal level from the satellite.

### **3.2.8. Tracking Receiver – Single Channel Per Carrier Receiver**

The SCPC Narrow Band Receiver located in the Antenna Control Unit (ACU) is used to acquire, identify and track a narrow band carrier, or beacon signal, or the desired satellite. When properly setup, the settings for

the satellite are saved to expedite future acquisition of the desired satellite. The system must have adequate satellite signal level to stop searching (and begin tracking the acquired satellite).

### 3.2.9. Tracking

The ACU actively optimizes the pointing of the dish for maximum signal reception. This process is called tracking and is accomplished by continuously making small movements of the dish while monitoring the level of the received signal. Evaluation of this information is used to continuously make minor pointing corrections to keep the signal level "peaked" as part of normal operation.

## 3.3. Components of the System Configuration

The following text provides a basic functional overview of the system components and component interconnection as referred to in the simplified block diagram below. Also, refer to the appropriate page of the System Block Diagram which depicts your system configuration for further detail.

The System is comprised of two major sections: The Above-Decks Equipment (ADE) is comprised solely of the antenna radome assembly which is mounted outside, on the boat's upper deck or mast location. The Below-Decks Equipment (BDE) includes the Antenna Control Unit, satellite modem and all other ancillary equipment that is mounted in various locations throughout the interior of the boat.

### 3.3.1. Antenna ADE Assembly

The Above Decks Equipment consists of an Antenna Pedestal inside a Radome assembly. The pedestal consists of a satellite antenna dish & feed with a linear Low Noise Block converter (LNB) with polarization motor mounted on a stabilized antenna pedestal.

The radome provides an environmental enclosure for the antenna pedestal assembly inside it. This keeps wind, water condensation and salt-water spray off the antenna pedestal assembly. This prevents damage and corrosion that would shorten the expected life span of the equipment.

Low loss coax cables are connected from the antenna radome assembly to the below decks equipment. The two cables carry the intermediate frequency (950-2050MHz) signals from the antenna assembly directly to the below decks equipment and below decks to antenna. Antenna control communication between the Antenna Control Unit and the Pedestal Control Unit are also on one of these coax cables.




Figure 3-2 2406 Above Decks Equipment

And finally an AC Power cable is also routed to the antenna to provide the operating voltage to the antenna assembly

### 3.3.2. Antenna Control Unit

The Antenna Control Unit allows the operator to control and monitor the antenna pedestal with dedicated function buttons, LED's and a 2 line display. The ACU and its Terminal Mounting Strip are normally mounted in a standard 19" equipment rack. The ACU should be mounted in the front of the equipment rack where it is easily accessible. The Terminal Mounting Strip is normally mounted on the rear of the equipment rack. It is recommended that the antenna control unit be mounted near the Satellite modem location where you can see the LED indicators while you are controlling the antenna.

The Antenna Control Unit is connected to the antenna, ship's Gyro Compass and Satellite modem.



**Figure 3-3 Antenna Control Unit**

The Antenna Control Unit (ACU) communicates via an RS-422 full duplex data link with the Pedestal Control Unit (PCU) located on the antenna. This control signal to/from the antenna is on the Coax cable along with the L-Band Receive IF from the LNB. The Pedestal Control Unit stabilizes the antenna against the ship's roll, pitch, and turning motions. The ACU is the operator interface to the PCU and provides the user with a choice of positioning commands to point the antenna, search commands to find the satellite signal and tracking functions to maintain optimum pointing. The operator may choose to work from either the front panel, using the M&C Port in conjunction with DacRemP remote diagnostic software, or the built in Ethernet port and a internal HTML page using a standard internet browser .

**3.3.3. Above Decks AC Power Supply**

**Pedestal Power** - An appropriate source of AC Voltage (110 VAC 60 Hz OR 220 VAC 50 Hz) is required for the above decks equipment. Total power consumption will depend on the number of equipments connected to this power source.

**RF Equipment (TX/RX Systems ONLY)** - The AC voltage source should be well regulated and surge protected. Uninterrupted Power Supplies are frequently installed (below decks) to provide power for the antenna pedestal, especially if RF Equipment is installed on the pedestal. Refer to the Specifications section of this manual for the power consumption of the antenna pedestal and RF Equipment.

**Marine Air Conditioner Unit (TX/RX Systems ONLY)** - If a marine air conditioner is included with your system, the AC voltage source should be from a separate AC Power breaker source than the antenna pedestal. AC power for the air conditioner should be well regulated and surge protected, but does NOT need to from an Uninterrupted Power Supply. Refer to the marine air conditioner manual for its' power requirements and consumption specifications.

This Page Intentionally Left Blank

## 4. Installation

Your antenna pedestal comes completely assembled in its radome. This section contains instructions for unpacking, final assembly and installation of the equipment. It is highly recommended that installation of the system be performed by trained technicians.

### 4.1. Unpacking and Inspection

Exercise caution when unpacking the equipment. Carefully inspect the radome surface for evidence of shipping damage.

### 4.2. Site Selection Aboard Ship

The radome assembly should be installed at a location aboard ship where:

- The antenna has a clear line-of-sight to as much of the sky (horizon to zenith at all bearings) as is practical.
- The antenna is a minimum of 15 Feet from the ship's Radar, further away if they are high power Radar arrays.
- The antenna is not mounted on the same plane as the ship's Radar, so that it is not directly in the Radar beam path.
- The antenna is a minimum of 15 Feet from high power short wave transmitting antennas.
- The Above Decks Equipment (ADE) and the Below Decks Equipment (BDE) should be positioned as close to one another as possible. This is necessary to reduce the losses associated with long cable runs.
- The mounting location is rigid enough that it will not flex, or sway, in ships motion or vibration. If the radome is to be mounted on a raised pedestal, it **MUST** have adequate gussets, or be well guyed, to prevent flexing or swaying in ships motion.

If these conditions cannot be entirely satisfied, the site selection will inevitably be a "best" compromise between the various considerations.

### 4.3. Assembly Notes and Warnings





**NOTE:** Unless otherwise indicated, all nuts and bolts should be assembled with Loctite 271 or its equivalent.

	<b>WARNING:</b> Assure that all nut & bolt assemblies are tightened according the tightening torque values listed below:	
	<b>Bolt Size</b>	<b>Inch Pounds</b>
	1/4-20	75
	5/16-18	132
	3/8-16	236
	1/2-13	517

#### 4.4. *Installing the Above-Decks Equipment (ADE)*


##### 4.4.1. **34" Radome Assembly**

The antenna pedestal is shipped completely assembled in its 34" radome.

	<p><b>WARNING:</b> <i>Hoisting with other than a webbed four-part sling may result in catastrophic crushing of the radome. Refer to the specifications and drawings for the fully assembled weight of your model Antenna/Radome and assure that equipment used to lift/hoist this system is rated accordingly.</i></p>
	<p><b>CAUTION:</b> <i>The antenna/radome assembly is very light for its size and is subject to large swaying motions if hoisted under windy conditions. Always ensure that tag lines, attached to the radome base frame, are attended while the antenna assembly is being hoisted to its assigned location aboard ship.</i></p>

1. Remove the shipping nuts which mount the ADE to its' pallet.
2. Using a web strap lifting sling arrangement, and with a tag line attached near the radome base, hoist the antenna assembly to its assigned location aboard ship by means of a suitably sized crane or derrick.
3. The radome assembly should be positioned with the BOW marker aligned as close as possible to the centerline of the ship. Any variation from actual alignment can be compensated with the AZIMUTH TRIM adjustment in the Antenna Control Unit so precise alignment is not required.
4. Bolt the radome base directly to the ship's deck or mounting plate. When completed the radome base should be as near level as possible.

##### 4.4.2. **Antenna Pedestal Mechanical Checks**



Web Strap(s)

Tie-wrap(s)

1. Remove the radome top to access the pedestal.
2. Inspect the pedestal assembly and reflector for signs of shipping damage.
3. Remove the web strap shipping restraints from the pedestal. Save these straps to restrain the antenna in the event that the AC power will be turned off while the ship is underway.
4. Cut and discard the large white tie-wraps and foam wrap from the pedestal.
5. Check that the antenna moves freely in azimuth, elevation, and cross level. This indicates the all the shipping restraints have been removed and that the bearings in all three axes are good.
6. Check that the antenna assembly is balanced front to back, top to bottom and side to side by observing that it remains stationary when positioned in any orientation. Refer to the Maintenance section of this manual for information on balancing the antenna.
7. Check that all pedestal wiring and cabling is properly dressed and clamped in place.
8. See cable terminations section below.

**4.5. Cable Installation**

**4.5.1. Shipboard Cable Installation**



**CAUTION:** Rough handling, tight bending, kinking, crushing and other careless handling of the cables and their connectors can cause severe damage.


The cables must be routed from the above-decks equipment group through the deck and through various ship spaces to the vicinity of the below-decks equipment group. When pulling the cables in place, avoid sharp bends, kinking, and the use of excessive force. After placement, seal the deck penetration gland and tie the cables securely in place.

**4.5.2. Cable Terminations In The Radome**

The TX, RX and AC Power cables must be inserted through the cable strain relief(s) through the base of the radome and connected appropriately.

The IF Coaxes are connected coax connector bracket. The AC Power cable should be routed through the clamp in the end of the breaker box and terminated to the breaker screw terminals.

Apply RTV to the strain relief joints and tighten the compression fittings to make them watertight



AC Power Input      TX Cable      RX Cable

1. Route AC Power cable into the breaker box and terminate to the breaker terminals.

2. Attach the TX and RX cables from below decks to the adapters. See the Radome Assembly and System Block Diagram drawings.
3. Close and fasten the radome hatch. Assure that the radome hatch is closed and secured when entry into the radome is no longer required.

#### **4.6. *Below Decks Equipment.***

##### **4.6.1. Antenna Control Unit Connections**

Refer to the ACU manual for installation information.

##### **4.6.2. Terminal Mounting Strip Connections**

Refer to the ACU manual for installation information.

##### **4.6.3. Control Cable Connections**

The Serial Control Cable is connected from the Base Multiplexer to the ACU. Refer to the ACU manual for installation information.

##### **4.6.4. NMEA GPS, Modem Lock & TX Inhibit Output Cable Connections**

The cable connection from TB 4 on the Terminal Mounting Strip to the Modem is **REQUIRED**. This connection provides:

- NMEA GPS output (allows the modem to adjust its link timing).
- Modem Lock output from the modem provides a logic input to the ACU to identify when it is on the correct satellite.
- A transmit inhibit output from the ACU will mute the modem transmit when the antenna is mis-pointed 0.5 degrees. This connection is **MANDATORY** to comply with new FCC Order 04-286 and WRC-03 Resolution 902.

##### **4.6.5. Ships Gyro Compass Connections**

Connect the cable from the ship's gyro compass repeater to TB1 or TB3 of the Terminal mounting strip. Use TB1 for a Step-By-Step gyro compass and match the connections to COM, A, B and C. Use TB3 for a Synchro gyro compass and match the connections to R1, R2, S1, S2 and S3.

##### **4.6.6. IF Cable Connections**

Attach the connectors on the TX and RX IF cables from above decks equipment to the BDE Rack. Attach the TX cable to the Satellite Modem "TX" connection. Attach the RX cable to the Base Multiplexer panel. RX IF cable from the Base Multiplexer is connected to the RF Input of the ACU. The RF Output of the ACU is then connected to the RX Input on the Satellite Modem.

##### **4.6.7. AGC Tracking Input Connections**

The RX cable from the Base Multiplexer panel provides the RF Input to the tracking receiver inside the ACU.

#### **4.7. *Broadband Connections Below Decks***

Refer to System Block Diagram for the Series 03 Ku-Band TX/RX System for connection information.

#### **4.8. *Set-up & Configuration***

Refer to the next section of this manual for set-up and configuration of the components in this system.

## 5. Set-up & Configuration

---

The components in the system will have been configured with IP Addresses at the factory. The Front Title Page of this manual has a list of recorded IP address information, serial number information and Modem software version.

In the paragraphs below you will verify the configuration of these components, which will also verify that each of them are communicating. If one of the components has been replaced, it will have to be configured correctly to properly operate as part of this system.

Contact Sea Tel for the Internet Service Provider (ISP) Network Operation Center (NOC) ASSIGNED IP address, SubNet Mask and the Primary & Secondary DNS addresses if they have not been previously provided to you, or if you have changed providers.

### 5.1. Operator Settings

Refer to the Operation chapter of this manual to set the Ship information. Latitude and Longitude should automatically update when the GPS engine mounted above decks triangulates an accurate location, but you may enter this information manually to begin. If your gyro source is providing Heading information in any format other than NMEA-0183 format, you will have to enter in the initial Ship's Heading position, the Gyro Compass will then keep the ACU updated.

Set the Satellite information, for the satellite you will be using. The receiver settings are especially important. At this point you should be able to target the desired satellite. Continue with the setup steps below to optimize the parameters for your installation.

### 5.2. Optimizing Targeting

First, assure that all of your Ship & Satellite settings in the ACU are correct. Target the desired satellite, immediately turn Tracking OFF, and record the Azimuth and Elevation positions in the "**ANTENNA**" display of the ACU (these are the **Calculated** positions). Turn Tracking ON, allow the antenna to "Search" for the targeted satellite and assure that it has acquired (and peaks up on) the satellite that you targeted. Allow several minutes for the antenna to "peak" on the signal, and then record the Azimuth and Elevation positions while peaked on satellite (these are the **Peak** positions). Again, assure that it has acquired the satellite that you targeted!

Subtract the Peak Positions from the Calculated Positions to determine the amount of Trim which is required. Refer to the ACU Setup information to key in the required value of Elevation Trim. Continue with Azimuth trim, then re-target the satellite several times to verify that targeting is now driving the antenna to a position that is within +/- 1.0 degrees of where the satellite signal is located.

EXAMPLE: The ACU targets to an Elevation position of 30.0 degrees and an Azimuth position of 180.2 (Calculated), you find that Peak Elevation while ON your desired satellite is 31.5 degrees and Peak Azimuth is 178.0. You would enter an EL TRIM value of -1.5 degrees and an AZ TRIM of +2.2 degrees. After these trims values had been set, your peak **on satellite** Azimuth and Elevation displays would be very near 180.2 and 30.0 respectively.

### 5.3. Optimizing Auto-Polarization TX/RX

If your system is fitted with a circular feed you do not need to optimize the polarity angle and can skip this procedure. This procedure optimizes the linear polarization of the feed. Verify that tracking is ON and that the antenna is peaked on your targeted satellite (targeting calculates the azimuth, elevation and polarization angles). Assure that you are in Auto-Pol mode (POL TYPE parameter in the ACU is set to 0072) and set your satellite modem (or spectrum analyzer) to view its signal level display. Go to the TX POLARITY parameter in the Setup menu of the ACU and set this parameter to your assigned Transmit polarity (Horizontal or Vertical). Go to the POL OFFSET parameter in the Setup menu of the ACU.

Default setting is 0040 and may be incremented, or decremented, to adjust polarization while in Auto-Pol mode. Each increment equals one degree of polarization rotation (0048 = +8 degrees), decrement below 40 for minus polarization (0032 = -8 degrees). Press the UP arrow to increment or the DOWN arrow to decrement the value and then hit the ENTER key to adjust the feed to the new value. *Allow 30 to 60 seconds between increments or decrements to allow time for feed assembly to drive to new position*

During commissioning, under guidance from the network operation center, you will be adjusting to minimize the effect of your transmission on the opposite polarization which maximizes your Cross-Pol isolation. Contact your satellite provider to help you (over the phone) to optimize the polarity angle for maximum Cross-Pol isolation (this optimizes your transmit polarity and is much more accurate than you trying to optimize your receive polarity). Save your new TX POLARITY and POL OFFSET values (refer to Save New Parameters in your ACU manual).

#### 5.4. Calibrating Relative Antenna Position (Home Flag Offset)

During initialization, azimuth drives the CW antenna until the Home Switch is contacted, which "presets" the relative position counter to the value stored in the Home Flag Offset. This assures that the encoder input increments/decrements from this initialization value so that the encoder does not have to be precision aligned.

The Home Switch is a hall sensor which is actuated by a magnet mounted on the azimuth driven sprocket, which produces the "Home Flag" signal.

The Home Flag Offset is a value saved in NVRam (Non-Volatile RAM) in the PCU. This value is the relative position of the antenna when the home switch is engaged. Presetting the counter to this value assures that when the antenna is pointed in-line with the bow of the ship the counter will read 000.0 Relative (360.0 = 000.0).

In most cases when the antenna stops at the home flag, it will be pointed in-line with the Bow of the ship. In these cases Home Flag Offset (HFO) should be set to zero. When "Optimizing Targeting" small variations (up to +/- 5.0 degrees) in Azimuth can be corrected using If AZ TRIM as described in the Optimizing Targeting procedure above.

Large variations in Azimuth position indicate that the Relative position is incorrect and should be "calibrated" using the correct HFO value instead of an Azimuth Trim offset. This is especially true if sector blockage mapping is used.

If the antenna stops at the home flag, but it is NOT pointed in-line with the Bow of the ship, it is important to assure that the antennas **actual** position (relative to the bow of the ship) is the value that gets "preset" into the Relative position counter. By saving the antennas **actual** Relative position when at the home flag into HFO, you have calibrated the antenna to the ship.




Figure 5-1 Antenna stops In-line with Bow

##### 5.4.1. To Calculate HFO:

If Targeting has been optimized by entering a large value of AZ TRIM; First, verify that you are able to repeatably accurately target a desired satellite (within +/- 1.0 degrees). Then you can use the AZ TRIM value to calculate the value of HFO you should use (so you can set AZ TRIM to zero). AZ Trim is entered as the number of **tenths** of degrees. You will have to convert the AZ TRIM value to the nearest **whole** degree (round up or down as needed). Calculated HFO value is also rounded to the nearest whole number.

If AZ TRIM was a **plus** value:  $HFO = (TRIM / 360) \times 255$  Example: AZ TRIM was 0200 (plus 20 degrees).  $HFO = (20/360) \times 255 = (0.0556) \times 255 = 14.16$  round off to 14.

If AZ TRIM was a **negative** value:  $HFO = ((360-TRIM) / 360) \times 255$  Example: AZ TRIM = -0450 (minus 45 degrees).  $HFO = ((360 - 45) / 360) \times 255 = (315 / 360) \times 255 = 0.875 \times 255 = 223.125$  round of to 223.

If Targeting has NOT been optimized, allow the antenna to initialize to its home flag position. Visually compare the antennas pointing to the bow-line of the ship (parallel to the Bow). Note the antennas position relative to the Bow. If it appears to be very close to being parallel to the bow, HFO will probably not be needed and you can proceed with Optimizing Targeting. If it is NOT close [initialization was driving the azimuth CW], note if the antenna appears to have stopped before it got to the Bow or if it went past the Bow. You may be able to guess an approximate amount of how many degrees the antenna is from the bow. This is only intended to help you initially find the satellite (which direction you will have to drive and approximately how far you will have to drive). Refer, in general terms, to the Optimizing Targeting procedure.

If the antenna stopped before it got to the bow-line; When you initially target a satellite, the antenna will also stop prior to the satellite position, so you that will have to drive the Azimuth of the antenna UP to actually find the satellite. Using the same basic procedure as in the Optimizing Targeting paragraph, target the satellite and record the "Calculated" Azimuth position that the antenna was driven to. Drive UP until you find the satellite, positively identify that you are on **the satellite** you targeted and allow tracking to peak the antenna position. Record the "Peak" Azimuth position. Subtract the "Peak" position from the "Calculated" position to determine the number of degrees of AZ TRIM that would be required.

**Example:** In this new installation, I target my desired satellite and record the Calculated Azimuth to be 180.5. I drive UP and finally find my desired satellite at a Peak Azimuth of 227.0 degrees. I subtract Peak from Calculated and difference to be -46.5 degrees, therefore the actual Relative position that needs to be preset into the counter when the antenna is at the Home Flag is 313.5.  $HFO = ((360-46.5) / 360) \times 255 = (313.5 / 360) \times 255 = 0.87 \times 255 = 222.06$  which I round down to 222.

If the antenna went past the bow-line; When you initially target a satellite, the antenna will also go past the satellite position, so that you will have to drive the Azimuth of the antenna DOWN to actually find the satellite. Using the same basic procedure as in the Optimizing Targeting paragraph, target the satellite and record the "Calculated" Azimuth position that the antenna was driven to. Drive DOWN until you find the satellite, positively identify that you are on **the satellite** you targeted and allow tracking to peak the antenna position. Record the "Peak" Azimuth position. Subtract the "Peak" position from the "Calculated" position to determine the number of degrees of AZ TRIM that would be required. . Refer to the calculations above to determine the HFO you should use for this antenna.

**Example:** In this new installation, I target my desired satellite and record the Calculated Azimuth to be 180.0. I drive DOWN and finally find my desired satellite at a Peak Azimuth of 90.0 degrees. I subtract Peak from Calculated and difference to be +90.0 degrees, therefore the actual Relative position that needs to be preset into the counter when the antenna is at the Home Flag is 90.0.  $HFO = ((90.0) / 360) \times 255 = 0.25 \times 255 = 63.75$  which I round up to 64.




Figure 5-2 Antenna stopped before the Bow




Figure 5-3 Antenna stops past the Bow

#### 5.4.2. To Enter the HFO value:

To enter the calculated HFO value, press & hold both LEFT and RIGHT arrows for six seconds to enter the parameter menu at the EL TRIM parameter window. Press DOWN arrow key numerous times (about 21) until you have selected the REMOTE COMMAND window.

In the REMOTE COMMAND window, press the LEFT arrow key until you have underscored the left most character in the displayed value (ie the A in "A0000"). Use the UP/DOWN arrow keys to increment/decrement the underscored character until it is upper case **N** ("N0000" should appear in the command window). Press the RIGHT arrow key to move the cursor under the most significant digit, then use the UP arrow key to increment it to a value of 6 (the display is now "N6000"). Set the three digits to the right of the 6 to the three digit HFO value from 000 to 255 (corresponding to 0 to 360 degrees) that you calculated above. Use the LEFT/RIGHT keys to underscore the desired digit(s) then use the UP/DONW arrow keys to increment/decrement the underscored value. When you have finished editing the display value, press ENTER to send the HFO value command to the PCU (but it is not save yet).

If you want to find out what the *current* HFO value is key in N6999 and hit **ENTER**.

When completed, you must save the desired HFO value. Press ENTER several times to select the REMOTE PARAMETERS display. Press the LEFT or RIGHT arrow key to enter writing mode and then press the ENTER to save the HFO value in the PCUs NVRAM.

**EXAMPLE:** In the "Antenna stopped before the Bow" example above, the HFO calculated was 222. To enter this value:

1. Set the Remote Command value to "N6222".
2. Press **ENTER** to send this HFO to the PCU. The display should now show "N0222".
3. When completed, you must save the desired HFO value. Press **ENTER** several times to select the **REMOTE PARAMETERS** display. Press the **LEFT** or **RIGHT** arrow key to enter writing mode and then press the **ENTER** to save the HFO value in the PCUs NVRAM.

You have to drive the antenna CW in azimuth until the home switch is actuated, or re-initialize the antenna to begin using the new HFO value you have entered and saved. To re-initialize the antenna from the REMOTE COMMAND window of the ACU;

4. Press **UP** arrow key several times to return to the **REMOTE COMMAND** display.
5. Press the **LEFT** or **RIGHT** arrow key to enter edit mode. Use the **LEFT/RIGHT** and **UP/DOWN** arrow keys to set the character and digits to "0090" and then press the **ENTER** key.

This resets the PCU on the antenna. The antenna will reinitialize with this command (Performs a similar function as a power reset of the antenna) and the new home flag offset value will be used to calibrate the Relative position of the antenna.

### 5.5. *Radiation Hazard and Blockage Mapping (AZ LIMIT parameters)*

This system may be programmed with relative azimuth and elevation sectors (zones) where blockage exists or where transmit power would endanger personnel who are frequently in that area.

Refer to your ACU Manual for instructions on programming of these zones.

### 5.6. TX Polarity Setup

With the feed in the center of its polarization adjustment range, observe the transmit port polarity (vector across the short dimension of the transmit wave-guide).

If the transmit polarity in the center of the travel range is vertical, use the following entries:

- 2 Vertical Transmit Polarity
- 4 Horizontal Transmit Polarity

If the Transmit polarity in the center of the travel range is horizontal, use the following entries:

- 2 Horizontal Transmit Polarity
- 4 Vertical Transmit Polarity

### 5.7. TRACK DISP

Your system **MUST** be fitted with quad-band LNB(s) for this function to change the frequency range of the LNB(s).

This parameter set the selections that the user will see in the Tracking - Band Selection menu. Band Selection **must** be set to the appropriate selection for Tracking to operate properly.

Band selection controls the **local** logic output state of SW1 output terminal on the Terminal Mounting Strip PCB and **remote** C/Ku relays (or other switches) on the antenna pedestal.

The factory default selections and SW1 status for your 9797B is listed in the following table:

Setting	Displayed band selection	ADE Band Select Parameters (Tone, Voltage & Aux Status)	TMS SW1 Status
0170	Band1	Tone OFF, Volt 13, Aux 0	Open
	Band2	Tone ON, Volt 13, Aux 0	Open
	Band3	Tone OFF, Volt 18, Aux 0	Short
	Band4	Tone ON, Volt 18, Aux 0	Short

When the SW1 output is shorted to ground a current sink of 0.5 amps **max** is provided to control below decks band selection tone generators or coax switches. When SW1 output is open it is a floating output.

### 5.8. Default Setup Parameters

The following table shows the factory default parameters for the DAC-2202, or DAC-2302, Antenna Control Unit interfaced to a Series 06 Antenna PCU. When the installation & setup of your system is finished you can record the "optimized" settings for your system in the "My Parameters" column. Also refer to the Antenna Control Unit Manual for more in-depth information each of the individual parameters and how to enter, or change the parameters.

PARAMETER	Setting	My Parameters
EL TRIM	0	
AZ TRIM	0	
AUTO THRES	100	
EL STEP SIZE	0	
AZ STEP SIZE	0	
STEP INTEGRAL	0	
SEARCH INC	20	
SEARCH LIMIT	100	
SEARCH DELAY	30	
SWEEP INC	0040	
SYSTEM TYPE	5*	
GYRO TYPE	2	
POL TYPE	72	
POL OFFSET	40	
POL SCALE	90	
AZ LIMIT 1	0	
AZ LIMIT 2	0	
EL LIMIT 12	0	
AZ LIMIT 3	0	
AZ LIMIT 4	0	
EL LIMIT 34	0	
AZ LIMIT 5	0	
AZ LIMIT 6	0	
EL LIMIT 56	0	
5V OFFSET	0	
5V SCALE	0	
TX POLARITY	2 (Horizontal TX)	
TRACK DISP	0170	

\* Modem Lock input & Modem TX Mute functions are NOT set, refer to SYSTEM TYPE parameter information.

## 6. Functional Testing

---

If not already ON, Turn ON the Power switch on the front panel of the ACU.

### 6.1. ACU / Antenna System Check

1. Press RESET on the ACU front panel to initialize the system. Verify the display shows "SEA TEL INC - MASTER" and the ACU software version number. Wait 10 seconds for the display to change to "SEA TEL INC - REMOTE" and the PCU software version number.
2. If the display shows "REMOTE INITIALIZING" wait for approximately 2 minutes for the antenna to complete initialization and report the Antenna Model and PCU software version. If "REMOTE NOT RESPONDING" is displayed, refer to the Troubleshooting Section of this manual.
3. Press the **NEXT** key repeatedly to display the *Ship*, *Satellite*, *Antenna* and *Status* menu displays. This verifies that the displays change in the correct response to the keys.

### 6.2. Latitude/Longitude Auto-Update check

This verifies that the GPS position information is automatically updating..

1. Press the **NEXT** key repeatedly to display the *Ship* menu. Press **ENTER** to access edit mode and view the current Latitude value.
2. Press the **LEFT** arrow key to bring the cursor up under the ones digit, press **UP** and then hit **ENTER**. The display should immediately show a latitude value one degree higher, but then will be overwritten within several seconds (back to the previous value) by the GPS engine.

This test does not need to be repeated in the Longitude menu.

### 6.3. Ship Heading – Gyro Compass Following Check

This verifies that the Heading display is actually following the Ships Gyro Compass.

1. Press the **NEXT** key repeatedly to display the *Ship* menu. If the boat is underway, monitor the Heading value to verify that the display changes in the correct response to the Gyro Compass input (Heading value should always be exactly the same as the Gyro Compass repeater value).
2. If the ship is NOT underway, most ships will turn +/- 1-2 degrees at the pier, monitor the Heading value to verify that the display changes in the correct response to the Gyro Compass input (Heading value should always be exactly the same as the Gyro Compass repeater value).

### 6.4. Azimuth & Elevation Drive

This verifies that the antenna moves in the correct response to the keys.

1. Press the **NEXT** key several times to display the Antenna menu.
2. Press the **TRACK** key to toggle Tracking OFF. Press the **UP** arrow key repeatedly and verify that the antenna moves up in elevation.
3. Press the **DOWN** arrow key repeatedly and verify that the antenna moves down in elevation.
4. Press the **RIGHT** arrow key repeatedly and verify that the antenna moves up (CW) in azimuth.
5. Press the **LEFT** arrow key repeatedly and verify that the antenna moves down (CCW) in azimuth.

### 6.5. Four Quadrant Tracking Test

This verifies that the antenna moves in the correct response to the keys, that Tracking is signaling correctly and that the Tracking commands are being carried out (antenna drives to peak).

1. Verify antenna is locked onto and tracking a satellite
2. Press the **NEXT** key several times to display the *Antenna* menu.
3. Note the current peak AGC value. Press the **Tracking** key to toggle Tracking OFF, press the **UP** arrow key repeatedly to move the antenna up in elevation until AGC falls about 100 counts. Turn Tracking ON and verify that the antenna moves back down in elevation and that the AGC rises to its' previous high value.

4. Note the current peak AGC value. Press the **Tracking** key to toggle Tracking OFF, press the **DOWN** arrow key repeatedly to move the antenna down in elevation until AGC falls about 100 counts. Turn Tracking ON and verify that the antenna moves back up in elevation and that the AGC rises to its' previous high value.
5. Note the current peak AGC value. Press the **Tracking** key to toggle Tracking OFF, press the **RIGHT** arrow key repeatedly to move the antenna up in azimuth until AGC falls about 100 counts. Turn Tracking ON and verify that the antenna moves back down in azimuth and that the AGC rises to its' previous high value.
6. Note the current peak AGC value. Press the **Tracking** key to toggle Tracking OFF, press the **LEFT** arrow key repeatedly to move the antenna down in azimuth until AGC falls about 100 counts. Turn Tracking ON and verify that the antenna moves back up in azimuth and that the AGC rises to its' previous high value.

### 6.6. *Blockage Simulation Test*

Blockage output function is used to modify the behavior of Tracking and Searching when there is a known blockage zone. The ACU provides a contact closure to ground on the SW2 terminal of the Terminal Mounting Strip when the antenna is pointed within any one of the blockage/hazard zones or the system is searching, targeting, unwrapping or is mis-pointed by 0.5 degrees or more (FCC TX Mute function for Transmit/Receive systems **only**). The contact closure is a transistor switch with a current sinking capability of 0.5 Amp. This logic output control signal is used for:

- When used as simple "BLOCKED" logic output for a single Sea Tel antenna, this output could be used to light a remote LED and/or sound a buzzer to alert someone that the antenna is blocked, and signal is lost.
- In a "Dual Antenna" installation, this logic output(s) is used to control Dual Antenna Arbitrator panel of coax switches to switch the source inputs to the matrix switch from Antenna "A" to Antenna "B", and vice versa.
- When used as simple "RF Radiation Hazard" logic output for a single Sea Tel TX/RX antenna, this output could be used to suppress RF transmissions while the antenna is pointed where people would be harmed by the transmitted microwave RF power output. The SW2 output would be interfaced to the satellite modem to **disable** the TX output signal from the Satellite TXRX Modem whenever the antenna is within the RF Radiation Hazard zone(s).
- When used for "FCC TX Mute" logic output for a single Sea Tel TX/RX antenna, this output could be used to suppress RF transmissions whenever the antenna is mis-pointed 0.5 degrees or more, is blocked, searching, targeting or unwrapping. The SW2 output would be interfaced to the satellite modem to **disable/mute** the TX output signal from the Satellite TX/RX Modem. When the mute condition is due to antenna mis-pointing, it will not **un-mute** until the pointing error of the antenna is within 0.2 degrees. The default output is contact closure to ground when the antenna is mis-pointed, therefore provides a **ground** to "Mute" the satellite modem on the SW2 terminal of the Terminal Mounting Strip. If your satellite modem requires an **open** to "Mute", refer to SYSTEM TYPE parameter 16 value to reverse the output logic from the ACU.

To Test the blockage function:






1. Press the NEXT key until you are at the Status menu. Press ENTER to access the Tracking menu.
2. Press the RIGHT arrow key to bring up and move the cursor to the far right. Press the UP arrow to simulate a manual BLOCKED condition. BLOCKED will appear in the Tracking display.
3. Verify that SW2 terminal shorts to ground (or open circuit if you have SYSTEM TYPE configured to reverse the output logic) and that the external alarms actuate OR the Dual Antenna Arbitrator coax switches toggle (if antenna B is not blocked) OR the Satellite Modem TX is disabled/muted.
4. Press the LEFT arrow key and then press the UP arrow key to turn the simulated blocked condition OFF. BLOCKED will disappear from the Tracking display.
5. Verify that SW2 terminal is open circuit (or ground if you have logic reversed) and that the external alarms deactivate OR the Satellite Modem TX is un-muted. The Dual Antenna Arbitrator coax switches should not toggle until you manually block Antenna B ACU.

### 6.7. *Test Broadband Operation*

Open you Internet Browser and access several internet sites, email or other functions as you normally would. Operation should be the same as any equivalent service ashore.

## 7. Maintenance and Troubleshooting

This section describes the theory of operation to aid in troubleshooting and adjustments of the antenna system. Also refer to the Troubleshooting section of your ACU manual for additional troubleshooting details.

	<p><b>WARNING:</b> <i>Electrical Hazard – Dangerous AC Voltages exist in the Breaker Box and the Antenna Pedestal Power Supply. Observe proper safety precautions when working inside the Antenna Breaker Box or Power Supply.</i></p>
	<p><b>WARNING:</b> <i>RF Radiation Hazard - This stabilized antenna system is designed to be used with transmit/receive equipment manufactured by others. Refer to the documentation supplied by the manufacturer which will describe potential hazards, including exposure to RF radiation, associated with the improper use of the transmit/receive equipment. Note that the transmit/receive equipment will operate independently of the stabilized antenna system.</i></p>
	<p><b>WARNING:</b> <i>RF Radiation Hazard - Prior to working on the stabilized antenna system, the power to the transmit/receive equipment must be locked out and tagged. Turning OFF power to the Antenna Control Unit does NOT turn Transmit power output OFF.</i></p>
	<p><b>WARNING:</b> <i>RF Radiation Hazard - When the transmit/receive system is in operation, no one should be allowed anywhere within the radiated beam being emitted from the reflector.</i></p>
	<p><b>WARNING:</b> <i>RF Radiation Hazard - When the transmit/receive system is in operation, no one should be allowed anywhere within the radiated beam being emitted from the reflector.</i></p>

### 7.1. Warranty Information

Sea Tel Inc. supports its Series 97, 00, 06 and 07 systems with a **ONE YEAR** warranty on parts and labor.

What's Covered by the Limited Warranty?

The Sea Tel Limited Warranty is applicable for parts and labor coverage to the complete antenna system, including all above-decks equipment (radome, pedestal, antenna, motors, electronics, wiring, etc.) and the Antenna Control Unit (ACU).

What's **NOT** Covered by the Limited Warranty?

It does **not** include Transmit & Receive RF Equipment, Modems, Multiplexers or other distribution equipment, whether or not supplied by Sea Tel commonly used in Satellite Communications (TXRX) Systems. These equipments are covered by the applicable warranties of the respective manufacturers.

Factory refurbished components used to replace systems parts under this warranty are covered by this same warranty as the original equipment for the balance of the original warranty term, or ninety (90) days from the date of replacement, whichever occurs last. Original Installation of the Series 97 system must be accomplished by or under the supervision of an authorized Sea Tel dealer for the Sea Tel Limited Warranty to be valid and in force.

Should technical assistance be required to repair your system, the first contact should be to the agent/dealer you purchased the equipment from.

Please refer to the complete warranty information included with your system.

### 7.2. Recommended Preventive Maintenance

Ensure that all of the normal operating settings (LAT, LON, HDG, SAT and all of the Tracking Receiver settings) are set correctly. Refer to the Functional Testing section to test the system.

**7.2.1. Check ACU Parameters**

Assure that the parameters are set correctly (you may wish to record them in the Factory Default Settings, in section 5 of this manual).

**7.2.2. Latitude/Longitude Auto-Update check**

Refer to the Latitude & Longitude Update check procedure in the Functional Testing section of this manual.

**7.2.3. Heading Following**

Refer to the Heading Following verification procedure in the Functional Testing section of this manual.

**7.2.4. Azimuth & Elevation Drive**

Refer to the Azimuth & Elevation Drive check procedure in the Functional Testing section of this manual.

**7.2.5. Test Tracking**

Refer to the four quadrant Tracking check procedure in the Functional Testing section of this manual.

**7.2.6. Visual Inspection - Radome & Pedestal**

Conduct a good, thorough, visual inspection of the radome and antenna pedestal. Visually inspect the inside surface of the radome top and of the antenna pedestal. Look for water or condensation, rust or corrosion, white fiberglass powder residue, loose wiring connections, loose hardware, loose or broken belts or any other signs of wear or damage.

1. Radome Inspection - All the radome flanges are properly sealed to prevent wind, saltwater spray and rain from being able to enter the radome. Re-seal any open ("leaky") areas with marine approved silicone sealant. If heavy condensation, or standing water, is found inside the radome, isolate and seal the leak, and then dry out the radome. Small (1/8 inch) holes may be drilled in the base pan of the radome to allow standing water to "weep" out.
2. Antenna Pedestal Inspection - The shock/vibration springs and/or wire rope Isolators should not be frayed, completely compressed, or otherwise damaged. The plated and painted parts should not be rusted or corroded. The harnesses should not be frayed and all the connectors should be properly fastened and tightened. All hardware should be tight (no loose assemblies or counter-weights). Replace, re-coat, repair and/or tighten as necessary.

**7.2.7. Mechanical Checks**

Turn the pedestal power supply OFF

1. Inspect inside of radome for signs that the dish or feed have been rubbing against the inside of the fiberglass radome.
2. Rotate the pedestal through its full range of azimuth motion. The antenna should rotate freely and easily with light finger pressure.
3. Rotate the pedestal through full range of elevation rotation. The antenna should rotate freely and easily with light finger pressure.
4. Rotate the pedestal through full range of cross-level rotation. The antenna should tilt (left/right) freely and easily with light finger pressure.
5. Rotate the level cage through the full 90 degrees of rotation from CCW stop to CW stop. The level cage antenna should rotate freely and easily with light finger pressure. Attached cables should not cause the cage to spring back more that a few degrees from either stop when released.
6. Inspect all drive belts for wear (black dust on/under the area of the belt).

**7.2.8. Check Balance**

Check the balance of the antenna, re-balance as needed (refer to the Balancing the Antenna procedure below).

**7.2.9. Observe Antenna Initialization**

Observe the Antenna Initialization as described in the Troubleshooting section below.

### 7.3. Troubleshooting

#### 7.3.1. Theory Of Stabilization Operation

The antenna system is mounted on a three axis stabilization assembly that provides free motion with 3 degrees of freedom. This assembly allows the inertia of the antenna system to hold the antenna pointed motionless in inertial space while the ship rolls, pitches and yaws beneath the assembly. Three low friction torque motors attached to each of the three free axes of the assembly provide the required force to overcome the disturbing torque imposed on the antenna system by cable restraints, bearing friction and small air currents within the radome. These motors are also used to re-position the antenna in azimuth and elevation.

The Pedestal Control Unit (PCU) uses inputs from the level cage sensors to calculate the amount of torque required in each axis to keep the antenna pointed within +/-0.2 degrees. The primary sensor input for each loop is the rate sensor mounted in the Level Cage Assembly. This sensor reports all motion of the antenna to the PCU. The PCU immediately responds by applying a torque in the opposite direction to the disturbance to bring the antenna back to its desired position. Both the instantaneous output of the rate sensor (Velocity Error) and the integrated output of the rate sensor (Position Error) are used to achieve the high pointing accuracy specification.

The calculated torque commands are converted to a 5 volt differential analog signal by a Digital to Analog converter (D/A) and sent to each of three Brush-Less Servo Amplifiers. These amplifiers provide the proper drive polarities and commutation required to operate the Brush-Less DC Servo Motors in torque mode. The Torque acting on the mass of the antenna cause it to move, restoring the rate sensors to their original position, and closing the control loop.

Since the rate sensors only monitor motion and not absolute position, a second input is required in each axis as a long term reference to keep the antenna from slowly drifting in position. The Level and Cross Level reference is provided by a two axis tilt sensor in the level cage assembly. The Azimuth reference is provided by combining the ships gyro compass input and the antenna relative position.

#### 7.3.2. Series 06 TXRX Antenna Initialization

Turn the pedestal power supply ON. The PCU will initialize the stabilized portion of the mass to be level with the horizon and at a prescribed Azimuth and Elevation angles. The antenna will go through the specific sequence of steps (listed below) to initialize the level cage, elevation, cross-level and azimuth to predetermined starting positions.

Initialization is completed in the following phases, each phase must complete properly for the antenna to operate properly (post-initialization). Observe the Initialization of the antenna pedestal.

Step 1. The level platform motor drives the Level Cage CCW, issuing extra steps to assure that the cage is all the way to the mechanical stop. Then the Level Cage will be driven exactly 45.0 degrees CW.

Step 2. Elevation axis then activates - Input from the LV axis of the tilt sensor is used to drive the Elevation of the equipment frame to bring the tilt sensor LV axis to level. This step takes approximately 10 seconds and will result in the dish being at 45.0 degrees in elevation. The level cage may still be tilted left or right at this time.

Step 3. Cross-Level axis activates - Input from the CL axis of the tilt sensor is used to drive Cross-Level of the equipment frame to bring the cross-level axis of the tilt sensor to level (this results in the tilt of the Cross-Level Beam being level). This step takes approximately 10 seconds.

Step 4. Azimuth axis activates - Antenna drives CW in azimuth until the "Home Flag" signal is produced. This signal is produced by a Hall Effect sensor in close proximity to a Magnet. After another 10 second wait, the antenna will report its version number at the Antenna Control Unit (ACU).

This completes the phases of initialization. At this time the antenna elevation should 45.0 degrees and Relative azimuth should be at home flag (home switch hall sensor at the magnet in the azimuth driven sprocket).

If any of these steps fail, or the ACU reports model "xx03", re-configure the PCU as described in the Maintenance section of this manual. If initialization still fails, this indicates a drive or sensor problem, refer to the Troubleshooting section.

### 7.3.3. Troubleshooting using DacRemP

While troubleshooting a Sea Tel 3-Axis Antenna System, you must classify the fault you are dealing with as a failure within one of 3 major system functions, Targeting, Stabilization, and Tracking. Should there be a failure with any one of these functions, your system will not operate properly. A few simple checks may help determine which fault (if any) that you are dealing with. The matrix below lists some test(s) and which of the DacRemP graph selection would be best to use to identify a fault. The end of this chapter contains examples on how to use DacRemP to diagnose a fault.

**Targeting:** is the ability to accurately point the antenna to an angular position in free space and is controlled by the ACU. (Does the system drive to the Azimuth, Elevation, and Polarity positions within 1 degree of the desired satellite?)

**Stabilization:** is the process of de-coupling the ships motion from the antenna and is controlled by the PCU. (Does the system maintain the satellite link after turning off TRACKING?)

**Tracking:** is the process of issuing fine adjustments to the **pointing** angle of the antenna to optimize the received signal level and is controlled by the ACU. (Does the system pass a four quadrant-tracking test?)


Functional Test(s)	DacRemP Graph Selection to use	System Function(s)
Four Quadrant Tracking.	ADMC (Position)	Tracking
Azimuth Encoder Verification.	ADMC (Position)	Targeting
Sea Trial	ADMC (Position)	Targeting Tracking Stabilization
Side Lobe Plots	ADMC (Position)	Tracking
Targeting Alignment (AZ & EL Trims)	ADMC (Position)	Targeting
Determine Blockage Mapping	ADMC (Position)	Tracking
Unwrap recovery (Limited Az systems only)	ADMC (Position)	Stabilization
Pedestal Gain Verification	DISPIVC (Loop Error)	Stabilization
Home switch (flag) verification (Unlimited Az systems only)	DISPV (Ref)	Stabilization
Remote Tilt Verification	DISPV (Ref)	Targeting Stabilization
Level cage alignment Verification (sensor alignment)	DISPV (Ref)	Targeting Stabilization
Rate Sensor Output Verification	DISPW (Rate)	Stabilization
Level and CL fine balance Verification	DISPTC (Drive)	Stabilization
AZ Friction Torque Test	DISPTC (Drive)	Stabilization
DishScan Drive/Phase	DishScan XY	Tracking Stabilization

### 7.3.4. Antenna Loop Error Monitoring


The DacRemP **DISPIVC** graph chart provides a means for monitoring the accumulated velocity errors of the antenna for diagnostic purposes. If this error is excessive, it indicates external forces are acting on the antenna. These forces may be the result of but not restricted to static imbalance, excessive bearing friction,

cable binding, or wind loading. If these forces cause the antenna to mis-point by more than 0.5° from the desired position the PCU will flag a "Stab Limit" error.

- To view the position error, select the **DisplVC (LoopError)** graph chart.




- This chart displays sensed axis errors via three traces, CL (Cross Level), LV (Elevation), and AZ (Azimuth), at a fixed 0.05°/ vertical division.
- The normal trace average will plots it's display  $\pm 3$  divisions from the red reference line. Any trace line average plotted above this is of concern and troubleshooting required. The example below shows the forces exerted onto the antenna as a resultant of DishScan Drive. The example below shows the results of various forces put upon antenna.



- Cross-Level Axis physically moved CCW (down to the left.) and then CW (up to the right.)

Elevation Axis physically moved CW. (reflector slightly pushed up) and then physically moved CCW. (reflector slightly pushed down.) At the end of chart recording shows




- DishScan Drive turned Off, notice the lack of accumulated IVC errors.


### 7.3.5. Reference Sensor Monitoring

The DacRemP **DISPV** graph chart provides a means for monitoring the output of the 2 Axis Tilt Sensor and the Home Switch sensor for diagnostic purposes. The Tilt sensor (located inside the Level Cage Assembly) is the primary input for the antenna's reference to the horizon (0° Elevation and 90° Cross-Level). While the Home Switch Sensor (located at the antenna base) is used to calibrate the antenna's position relative to the vessels BOW.

- To view the reference sensors, select the **Disp V (Ref)** graph chart.
- This chart displays the output of the Tilt Sensor via two traces, CL (Cross Level), LV (Elevation) at a fixed 1°/ vertical division, and the home flag logic level via a single trace, AZ (Azimuth).



- The normal trace display for the Tilt Sensor, after performing remote tilt calibration, will be  $\pm 4$  divisions from the red reference line. Any trace line average plotted above this is of concern and troubleshooting required. See below for a screen capture of an antenna that is Level in both the Cross-Level and Elevation Axis.
- The Cross Level Tilt display should plot on the red reference line when the level cage is level, referenced to the horizon. It should decrease (plots below red line) when the antenna is tilted to the left and increase (plots above red line) when tilted to the right. See below for a screen capture of an abnormal CL trace Plot, it is an indication that the antenna that is either listed to the right approx. 4 degrees or the PCU requires to much CL tilt bias.




- The Level tilt display should plot on the red reference line when the level cage is level, referenced to the horizon. It should decrease (plots below red line) when the antenna is tilted forward (EL down) and increase (plots above red line) when tilted back (EL up).
- The Azimuth display for the Home Switch will normally display a logic level high (plots directly on Red reference line after clicking on the **Center All** button) when the home flag is NOT engaged and changing to a logic level low when engaged. See below for a screen capture of an antenna that was driven so that the Home Flag switch is engaged.



### 7.3.6. Open Loop Rate Sensor Monitoring

The DacRemP **DISPW** graph chart provides a means for monitoring the output of the 3 solid state rate sensors (located inside the Level Cage Assembly) for diagnostic purposes. The rate sensors are the primary inputs to the PCU for stabilization.

- To monitor the rate sensors, select the **Disp W (Rate)** graph chart
- This chart displays sensed output from the 3 rate sensors via three traces, CL (Cross Level), LV (Elevation), and AZ (Azimuth), at a fixed 1°/Second/vertical division.
- A normal trace display will be  $\pm 1$  divisions from the red reference line. The example shown below shows an antenna that is NOT currently sensing motion in any axis.




- The Cross Level display should decrease (plots below red line) as the antenna is tilted to the left and increase (plots above red line) as the antenna tilted to the right.
- The Level display should decrease (plots below red line) as the antenna is tilted forward and increase (plots above red line) as the antenna is tilted back.
- The Azimuth display should decrease (plots below red line) as the antenna is rotated CCW and increase (plots above red line) as the antenna is rotated CW. In the example below, the output of the Azimuth rate sensor is plotted above the reference line, indicating that the antenna was driven CW in Azimuth. Due to the in-practicality of driving an axis at a consistent rate, verification of rate sensor output is, for the most part restricted to a positive or negative response of the Level Cage movement (plotting above or below the red reference line of each axis).



### 7.3.7. Open Loop Motor Test

The DacRemP **Comm Diagnostics** Window provides a means to enter in Remote Commands for driving each individual torque motor to test that motors functionality. By driving each axis and observing the resulting motion of the antenna, a coarse operational status of the motor and motor driver may be established.

- To manually drive the motors, select the “**Comm Diagnostics**” window under to the Tools submenu or Press “CTRL + C”
- Using the small field in the upper left hand corner of the window, type in the remote command and verify the motor appropriately drives in the direction commanded.
- To drive the Cross Level motor, key in ^1064, ^1128 or ^1192 and press **ENTER** to drive the Cross Level axis LEFT, OFF or RIGHT respectively.
- To drive the Level motor, key in ^2064, ^2128 or ^2192 and press **ENTER** to drive the level axis FORWARD, OFF or BACKWARD respectively.
- To drive the Azimuth motor, key in ^3064, ^3128 or ^3192 and press **ENTER** to drive the azimuth axis CW, OFF or CCW.



### 7.3.8. To Disable/Enable DishScan

To be able to use Step Track, or to revert to Conscan, as your active tracking mode you will have to disable DishScan.

Select the **DISHSCAN** parameter window on the ACU:

1. Press the RIGHT arrow, then press the UP arrow and last press the ENTER key to turn DishScan mode ON.
2. Press the RIGHT arrow, then press the DOWN arrow and last press the ENTER key to turn DishScan Mode OFF.

If you change this remote parameter, you must save the change using REMOTE PARAMETERS.

If DishScan is **OFF** and the **Step Integral** parameter is set to **0000**, you will get a **constant ERROR 0016** (DishScan error) and you will see **zeros** flashing in the lower left of the Azimuth and Elevation ENTRY menu displays. This is a visual indication that DishScan is turned OFF.

### 7.3.9. Satellite Reference Mode

The ships gyro compass input to the ACU may be accurate and stable in static conditions and yet may NOT be accurate or stable enough in some underway dynamic conditions. If there is no gyro compass or if the input is corrupt, not stable or not consistently accurate the tracking errors will become large enough to cause the antenna to be mis-pointed off satellite.

Satellite Reference Mode will uncouple the gyro reference from the azimuth rate sensor control loop. This decoupling of the Gyro source only happens 5 minutes after an azimuth command has been sent to the antenna by means of an AZ target command, a search pattern initiated, or the a Satellites longitudinal position is targeted. When operating in Satellite Reference Mode changes in ships gyro reading will reflect its changes to the ACU's display but will not directly affect the azimuth control loop. The Pedestal Control Unit will stabilize the antenna based entirely on the azimuth rate sensor loop and the tracking information from DishScan. This will keep the azimuth rate sensor position from eventually drifting away at a rate faster than the tracking loop can correct by using the tracking errors to regulate the rate sensor bias.

Satellite Reference Mode can be used as a diagnostic mode to determine if tracking errors are caused by faulty gyro inputs.

Satellite Reference Mode **MUST be used when:**

- No Gyro Compass is available
- Frequent or constant ACU Error Code 0001 (Gyro Compass has failed)

- Gyro Compass output is NMEA heading
- Flux Gate Compass is being used
- GPS Satellite Compass is being used




To view, or change, the Satellite Reference Mode status, select the SAT REF remote parameter:


1. Press the RIGHT arrow, then press the UP arrow and last press the ENTER key to turn Satellite Reference Mode ON.
2. Press the RIGHT arrow, then press the DOWN arrow and last press the ENTER key to turn Satellite Reference Mode OFF.

If you change this remote parameter, you must save the change using REMOTE PARAMETERS.

**7.3.10. To Read/Decode an ACU Error Code 0008 (Pedestal Function Error):**

An Error Code 8 as reported by the ACU is an indication that the above decks equipment has experienced an error. One of the functions available within the “Comm Diagnostics” tool window provides the means to read and decode the actual discreet Pedestal Function Error.

<p>1. Select the “Comm Diagnostics” window under to the Tools submenu or Press “CTRL + C”</p>	
<p>2. Left mouse click on the  icon.</p>	




<p>3. Right mouse click on the  icon.</p> <p>This will display a list box with the status of the above decks pedestal filtered into 3 sections. Items preceded with a check marks indicate a flagged status. See matrix below for further information on each state.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Slow Scan</p> <p>Sat Reference</p> <p><input checked="" type="checkbox"/> DishScan</p> <p>Unwrap</p> <p>Data 3</p> <p><input checked="" type="checkbox"/> Data 2</p> <hr/> <p>AZ Target</p> <p>Az Velocity</p> <p><input checked="" type="checkbox"/> Valid Heading (PCU)</p> <p>PCU Error</p> <p>PCU Init</p> <p>Hi Elevation</p> <hr/> <p>Sensor Limit</p> <p>Stability Limit</p> <p>AZ Reference Error</p> <p>AZ Servo Limit</p> <p>LV Servo Limit</p> <p>CL Servo Limit</p> </div>
---	--


State	Description
<b><i>PCU Status (Word 1)</i></b>	
Slow Scan	Indicates antenna is in a specialized mode, Slow Scan, which is required when ever a test requires driving the antenna >5°/sec
Sat Reference	Indicates that satellite reference mode is enabled.
DishScan	Indicates that DishScan Drive is enabled.
Unwrap	Indicates that the antenna is currently in an "Unwrap" state. This is not a valid error for unlimited azimuth antenna systems
Data 3	Indicates active communication between above decks and below decks equipment at the time of query
Data 2	Indicates active communication between above decks and below decks equipment at the time of query
<b><i>PCU Status (Word 2)</i></b>	
Az Target	Indicates the antenna is currently targeting a pre-determined azimuth position
Az Velocity	**Not a valid state**
Valid Heading (PCU)	Indicates that the PCU has received and integrated the heading value from the ACU into the Azimuth Stabilization Loop. This is NOT an indication of a proper Heading integration into ACU.
PCU Error	Indicates that one or more errors have been reported by the above decks equipment.
PCU Init	Indicates that the above decks equipment is currently performing an Initialization sequence
Hi Elevation	Indicates that the above decks equipment is operating an Elevation Position higher than 83°

<b>PCU Error Status (Word 3)</b>	
Sensor Limit	**Not a valid state**
Stability Limit	Indicates that the above decks equipment is mis-pointed from its intended target by more than 0.5°. (FCC Tx Mute Compliance)
AZ Reference Error	Indicates a failure to integrate one the reference inputs within the Azimuth Stabilization Loop.
AZ Servo Limit	Indicates the current draw through the Azimuth Servo Amplifier (motor driver PCB) has exceeded what is required during normal operation
LV Servo Limit	Indicates the current draw through the Elevation Servo Amplifier (motor driver PCB) has exceeded what is required during normal operation
CL Servo Limit	Indicates the current draw through the Cross-Level Servo Amplifier (motor driver PCB) has exceeded what is required during normal operation

**7.3.11. Remote GPS LAT/LON Position:**

The above decks equipment has an integrated on board Furuno GPS antenna system. The Latitude and Longitude position information provided are utilized to calculate the Azimuth, Elevation, Cross-level and Polarity pointing angles of the desired satellite. The DacRemP “**Comm Diagnostics**” Window provides a means to query the GPS antenna to verify proper operation. The procedure below describes this process.

<p>1. Select the “<b>Comm Diagnostics</b>” window under to the Tools submenu or Press “CTRL + C”</p>	
<p>2. Left mouse click on the  icon.</p>	

<p>3. Left Mouse click on the "?@ PCU GPS position, 1 min (1 Nm)"</p>	<pre>? v PCU Version ? v References ? x IVC Loop Error ? y Torque Drive ? @ PCU GPS position, 1 min (1 Nm) ----- ^0067 DishScan Toggle ^0071 Sat Reference Mode ^0070 Slow Scan Mode ^0084 Tilt/Test Mode ^0000 Normal Mode ^0087 Save PCU Parameters ----- ^0090 Reboot PCU ^0082 Clear AZ HF Err Reset PCU Error Status</pre>
<p>4. In the "Response" window verify proper GPS position to within 1 nautical mile of your current position.</p> <p>The Latitude &amp; Longitude position of the GPS will be displayed in the following format: "@ LAT,N,LON,E,A"</p> <p>Where LAT and LON are in degrees and minutes, LAT will be followed by N or S (North or South), LON will be followed by E or W (East or West), then a status character and finally a checksum character.</p>	
<p>Furuno default value is in Japan at 34.4N 135.2E (@3444,N,13521,E,,_).</p> <p>After acquiring a good fix at Sea Tel the string is @3800,N,12202,W,A^ for our 38N 122W Latitude and Longitude position.</p> <p>The status character tells you the status of the GPS.          "," (Comma) = GPS has NOT acquired a proper fix,          "N" = GPS fix is NOT valid          "A" = GPS has acquired a valid fix.</p>	

## 7.4.Maintenance

### 7.4.1. Balancing the Antenna

The antenna and equipment frame are balanced at the factory however, after disassembly for shipping or maintenance, balance adjustment may be necessary. Balancing must be done with the power supply turned OFF. No belt removal is required to balance the antenna pedestal. Balancing is accomplished by adding or removing balance trim weights at strategic locations to keep the antenna from falling forward/backward or side to side. The antenna system is not pendulous so 'balanced' is defined as the antenna remaining at rest when left in any position. The antenna should be balanced within one or two ounces at the typical trim weight location of 2 feet from the axis of rotation.

The recommend balancing order is Elevation Axis with the antenna pointed at the horizon (referred to as front to back balance). Elevation Axis with the antenna pointed at zenith (referred to as top to bottom balance). Then Cross Level axis at any elevation position (referred to as side to side balance). The balance about azimuth axis is accomplished by accurately positioning the cross level beam in the azimuth stabilization assembly. This adjustment is done at the factory using special alignment tools. Do NOT attempt to adjust the cross level beam position in the field without the proper test fixtures.

### 7.4.2. To Adjust Tilt:

A REMOTE TILT calibration is required to align the level cage assembly correctly so that all sensors will be aligned accurately to the axis they relate to. The fluid filled tilt sensor provides a two dimensional horizon reference. The system is not able to automatically calculate the exact center value, therefore it is necessary to perform this procedure to manually enter any offset required to make sure the PCU receives a true reference to the horizon. The procedures below describes the process of performing this calibration from either the ACU front panel or DacRemP diagnostic software by connecting the ACU's RS-422 M&C Port to an available serial port on a Laptop/Desktop computer using a standard 9 pin serial cable.

#### Step 1 Turn Off DishScan Drive.

Using the DAC2202 ACU Front Panel:




1. Go to Remote Command window by pressing and holding the two **LEFT & RIGHT** arrows




until the EL TRIM parameter is displayed.

2. Press and release both **Left & Right** arrow keys again. The "SAVE NEW PARAMETERS" window should now be displayed.

3. Press either the  **ENTER** key or the  **DOWN** key until the "REMOTE DishScan TG" parameter is displayed.

4. Press the  **RIGHT** arrow to activate selection, then press the  Up arrow to toggle state to OFF. Press the  **ENTER** key (Note: You will see that an error code 16 is generated when DishScan movement is off.)


Using DacRemP:

1. Click on the  icon in the Comm Diagnostics window. (Verify that DishScan is turned off by clicking the Error LED on main display panel, there should be a check mark next to Conscan/DishScan)


(Steps 2-7 will require assistance to observe and operate antenna simultaneously)


**Step 2:** At Antenna, If not already installed, place a circular level bubble on top lid of level cage.


**Step 3:** On the ACU front Panel, press either the  **ENTER** key or the  **DOWN** arrow key until the **REMOTE TILT** window is displayed


**Step 4:** Push the  **RIGHT** arrow key to activate the Remote Tilt Mode.

**Step 5:** Based on the feedback from the technician observing the circular bubble, the technician which operating the ACU will need to use the arrow keys to rotate the stabilized antenna mass from front to back and left to right. You should wait at least 10 seconds between commands to allow time for sensor to settle.

 Left arrow will rotate antenna mass down to the left in the Cross-Level axis ½ degree

 **Right** arrow will rotate antenna mass up to the right in the Cross-Level axis ½ degree

 Up arrow will rotate antenna mass up in the Level axis ½ degree

 **Down** arrow will rotate antenna mass down in the Level axis ½ degree

When correct the Bubble should be as close to the center of the fluid as possible.




**Step 6:** Press  **ENTER** key to exit Remote Tilt Mode.

**Step 7:** Verify Tilt Bias entered is within specifications.

From antenna:




2. Observe the bubble for approximately 3-5 minutes to ensure it remains centered.

Using DacRemP:

1. Select the  reference sensor graph.
3. Verify the CL and LV displays are steady and within 4 divisions of nominal. (Anything more than 4 divisions above or below red reference line should be of concern and troubleshooting is required)

**Step 8:** Save Level and Cross-Level Tilt Bias values.

Using the DAC2202 ACU Front Panel:

4. Press  **DOWN** arrow or enter until you see "REMOTE PARAMETERS" window is displayed
2. Press  **RIGHT** arrow and then press  **ENTER** key (you will see a confirmation saying 'SAVED')

Using DacRemP:

5. Click  icon on the Remote Command window. (Verify ^0087 is displayed in the "Last Sent Command" window)

This saves the new tilt bias settings in the PCU. Reset or re-initialize the antenna to verify that the Level cage is properly level with the new settings.

### 7.4.3. To Reset/Reinitialize the Antenna:

Pressing Reset on the ACU front panel does NOT cause a reset of the above decks equipment. To Re-initialize the antenna from the **REMOTE COMMAND** window on the ACU:

1. Using the **LEFT/RIGHT** and **UP/DOWN** arrow keys set the Remote Command value to "**^0090**" and press **ENTER**.

This resets the PCU on the antenna. The antenna will reinitialize with this command (Performs a similar function as a power reset of the antenna).

### 7.5. Pedestal Control Unit Configuration – Series 06

The PCU is designed to be used with a variety of antenna pedestal models. So, the PCU must be configured correctly for the model number of the antenna it is mounted on. The configuration information that is unique to each pedestal model is stored in a Non Volatile Random Access Memory (NVRAM) in the PCU enclosure. If the PCU is replaced or the NVRAM in the PCU should become corrupt, the PCU must be re-configured to operate with the pedestal it is installed on. The default configuration for the PCU is model **xx03, xx04 or xx06**. *In this configuration the Level Cage will drive normally but the PCU will not drive any of the three torque motors to prevent damage to the unknown pedestal.*

#### 7.5.1. To configure the PCU:

1. Select the REMOTE COMMAND window on the ACU.
2. Refer to the table below to key in the appropriate value for you model antenna to enter in the next step. **EXAMPLE:** For a **4006** Model Antenna, select system type 0020.
3. Using the **LEFT/RIGHT** and **UP/DOWN** arrow keys set the Remote Command value to "**N0020**" and press **ENTER**. The display should now show "N0020".
4. Press **ENTER** several times to select **REMOTE PARAMETERS**. Press **LEFT** arrow and then **ENTER** to save the system type in the PCU.
5. Press **RESET** and the displayed Remote Version Number should now display "**4006 VER 2.nn**".

#### 7.5.2. Model Configuration Numbers

The following table shows the current mode configuration values for Series 06 pedestals.

MODEL	Configuration Number
xx03/xx06	N 0000 Turns off all drive motors
<b>2406</b>	<b>N 0017</b>
4006	N 0020
4006-10	N 0021
6006RZA Ku	N 0022
6006RZA C	N 0023
4006RZA	N 0024

## 8. 2406-51 Technical Specifications

---

The specifications of your 4006 antenna system are below.

### 8.1. Antenna Reflector/Feed 2406

Type	Spun Aluminum axis symmetric reflector
Size	24 inch (61.0cm)
Feed	Center focus Cassegrain feed with Co-Pol or Cross-Pol OMT
LNB (s)	Single output Linear LNBS can be provided; for 10.95-11.7 GHz, 11.7-12.2 GHz or 12.2-12.75 GHz frequency bands.
Polarization	Linear w/motorized skew adjustment
Polarization control	24 volt DC motor with pot feedback
Antenna Gain	
TX Gain	36 dBi at 14.0 GHz Typical – in the Radome
RX Gain	34 dBi at 10.75 GHz Typical – in the Radome
Transmit frequency range	14.0-14.5 GHz Ku Band
Receive frequency range	10.95-12.75 GHz Ku Band

### 8.2. RF Equipment

25W SSPBUC (Block Up-Converter)	Wavestream, Ku-Band, 25 Watt
Power Supply	Wavestream, ICD-00-XSA-0002, Matchbox 48Vdc
Transmit Frequency	14.0-14.5 GHz (Standard) 13.75-14.5 GHz (Extended Band Option)
IF Frequency	950-1450 MHz (Standard) 950-1700 MHz (Extended Band Option)
Ku PLL LNB Input Frequency	11.70-12.20 GHz
8W SSPBUC (Block Up-Converter)	Wavestream, Ku-Band, 8 Watt
Power Supply	Wavestream, ICD-00-XSA-0002, Matchbox 48Vdc
Transmit Frequency	14.0-14.5 GHz (Standard) 13.75-14.5 GHz (Extended Band Option)
IF Frequency	950-1450 MHz (Standard) 950-1700 MHz (Extended Band Option)
Ku PLL LNB Input Frequency	11.70-12.20 GHz

### 8.3. Pedestal Control Unit

The PCU Assembly contains 2 Printed Circuit Boards (PCBs). One is the main control board and the other is the Motor Driver for the 3 Brushless DC Drive motors (AZ/EL/CL).

Connectors	
Antenna Pedestal	44 Pin D-Sub connector
Motor Interface	25 Pin D-Sub connector
M&C Interface	15 Pin D-Sub connector
GPS Input	BNC connector
Controls	None
M&C Interface	9600 Baud RS-422

**8.4. Stabilized Antenna Pedestal Assembly**

Type:	Three-axis (Level, Cross Level, AZ)
Stabilization:	Torque Mode Servo
Stab Accuracy:	0.3 degrees MAX, 0.15 degrees RMS in presence of specified ship motions (see below).
LV, CL, AZ motors:	Size 23 Brushless DC Servo.
Inertial Reference:	Solid State Rate Sensors
Gravity Reference:	Two Axis Fluid Tilt Sensor
AZ transducer:	256 line optical encoder / home switch
Pedestal Range of Motion:	
Elevation	-15 to +105
Cross Level	+/- 25 degrees
Azimuth	Unlimited
Elevation Pointing	+0 to +90 degrees at 15 degree roll/pitch +5 to +80 degrees at maximum specified roll +10 to +75 degrees at maximum combined roll & pitch
Maximum Specified Ship Motions	
Roll	+/- 25 degrees
Pitch	+/- 15 degrees
Yaw	Unlimited
Specified Ship Motions (for stabilization accuracy tests):	
Roll:	+/-20 degrees at 8-12 sec periods
Pitch:	+/-10 degrees at 6-12 sec periods
Yaw:	+/-8 degrees at 15 to 20 sec periods
Turning rate:	Up to 12 deg/sec and 15 deg/sec/sec
Headway:	Up to 50 knots
Mounting height:	Up to 150 feet.
Heave	0.5G
Surge	0.2G
Sway	0.2G

**8.5. Radome Assembly, 34"**

Type/Material:	Rigid fiberglass dome
Material:	Composite foam/fiberglass
Size:	
Diameter:	34 inches
Height:	39 inches
Installed weight	250 pounds <b>MAX</b> including antenna
RF attenuation:	1.5 dB at 12 GHz, dry 1.5 dB @ 14 GHz, dry
Wind:	Withstand relative average winds up to 100 MPH from any direction.

**\*NOTE: Radome panels can absorb up to 50% moisture by weight. Soaked panels will also have higher attenuation.**

**8.6. Unlimited Azimuth Modem/Multiplexer (3 Channel)**

## Combined Signals (-1,-2)

Pass-Thru	70, 140, 950-2050 MHz RX IF, 22Khz Tone DC LNB Voltage Select
Injected	1.1 / 1.5Mhz Pedestal M&C

## Connectors:

RX IF	F female
Rotary Joint	SMA female
DC / Ped M&C	9 pin D-Sub Connector

## Pedestal M&amp;C

Modulation	FSK
Mode	Full Duplex
Frequencies	1.1/1.5 MHz

## Combined Signals (-5)

Pass-Thru	70, 140, 950-2050 MHz RX IF, 22Khz Tone
-----------	--

Injected	1.1 / 1.5Mhz Pedestal M&C DC LNB Voltage Select
----------	--

## Connectors:

RX IF	F female
Rotary Joint	SMA female
DC / Ped M&C	9 pin D-Sub Connector

## Pedestal M&amp;C

Modulation	FSK
Mode	Full Duplex
Frequencies	1.1/1.5 MHz

**8.7. ADE Pedestal Power Requirements:**

Antenna AC Input Power	110/220 VAC, 60/50 Hz, single phase
Antenna Power Consumption	100 Watts <b>MAX</b>

**8.8. Environmental Conditions (Above Decks Equipment)**

Temperature:	-20 degrees C to 55 degrees C.
Humidity:	Up to 100% @ 40 degrees C., non-condensing.
Spray:	Resistant to water penetration sprayed from any direction.
Icing:	Survive ice loads of 4.5 pounds per square foot. Degraded RF performance will occur under icing conditions.
Rain:	Up to 4 inches per hour. Degraded RF performance may occur when the radome surface is wet.
Wind:	Withstand relative average winds up to 100 MPH from any direction.
Vibration:	Withstand externally imposed vibrations in all 3 axes, having displacement amplitudes as follows:
Frequency Range, Hz	Peak Single Amplitude
4 - 10	0.100 inches (0.16 to 1.0G)
10 - 15	0.030 inches (0.3 to 0.7G)
15 - 25	0.016 inches (0.4 to 1.0G)
25 - 33	0.009 inches (0.6 to 1.0G)
Corrosion	Parts are corrosion resistant or are treated to endure effects of salt air and salt spray. The equipment is specifically designed and manufactured for marine use.

**8.9. Below Decks Equipment****8.9.1. DAC-2202 Antenna Control Unit (ACU)**

Refer to the DAC-2202 Manual for its specifications.

**8.9.2. Terminal Mounting Strip (TMS)**

Refer to the DAC-2202 Manual for the TMS specifications.

**8.9.3. Satellite Modem**

Please refer to the manufacturers I&O manual for this device.

**8.9.4. Router**

Please refer to the manufacturers I&O manual for this device.

## 8.10. Cables

### 8.10.1. Antenna Control Cable (Provided from ACU-Base MUX)

RS-422 Pedestal Interface

Type	Shielded Twisted Pairs
Number of wires	4
Wire Gauge	24 AWG or larger
Communications Parameters:	9600 Baud, 8 bits, No parity
Interface Protocol:	RS-422
Interface Connector:	DE-9P

### 8.10.2. Antenna L-Band IF Coax Cables (Customer Furnished)

Due to the loss across the length of the RF coaxes at L-Band, Sea Tel recommends the following coax cable types (and their equivalent conductor size) for our standard pedestal installations:

Run Length	Coax Type	Center Conductor Size	Typ. Loss @ 1750Mhz
up to 150 ft	LMR-400	14 AWG	5.571 db/100'
up to 200 ft	LMR-500	10 AWG	4.496 db/100'
Up to 300 ft	LMR-600	6 AWG	3.615 db/100'

### 8.10.3. AC Power Cable Above Decks (Customer Furnished)

Voltage:	110 or 220 volts AC, 50/60 Hz., single phase
Type:	Multi-conductor, Shielded
Number of wires	3 Conductors
Wire Gauge:	Use proper wire gauge for the length of the power cable run.
Insulation:	600 VAC

### 8.10.4. Gyro Compass Interface Cable (Customer Furnished)

Type:	Multi-conductor, Shielded
Number of wires	4 Conductors for Step-By-Step, 5 Conductors for Synchro
Wire Gauge:	See Multi-conductor Cables spec above
Insulation:	600 VAC

This Page Intentionally Left Blank

## 9. DRAWINGS

---

The drawings listed below are provided as apart of this manual for use as a diagnostic reference.

### 9.1. 2406-51 Ku-Band Model Specific Drawings

Drawing	Title	
129293-2_A	2406-51 System, 34" Radome	9-3
129296-1_A	2406-51 System Block Diagram	9-5
129295-1_A	2406-51 General Assembly	9-8
129297_A	Antenna System Schematic	9-12
124226-2_	2406 Antenna Assembly	9-13
125808-1_B	34" Radome Assembly	9-16
122663_B4	Installation Arrangement	9-19


### 9.2. 2406 General Drawings

Drawing	Title	
127421-1_A	Standard Spare Parts Kit	9-20
127422-1_A	Premium Spare Parts Kit	9-21
127423-1_A	Master Spare Parts Kit	9-22
124348_B3	Pedestal Harness Schematic	9-23
121628-4_N2	Terminal Mounting Strip	9-24
116881-3_K	Base Multiplexer Panel	9-26


This Page Intentionally Left Blank

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	129295-1	A	GENERAL ASS'Y, 2406-51	
2	1 EA	125808-1	B	RADOME ASS'Y, 24XX GA INSTALL, 34 IN	
3	1 EA	126745-4	A2	BUC, KU-BAND, 8W, NO FAN, WAVESTRE	
4	1 EA	127396-1	A	POWER SUPPLY, 48 VDC, WAVESTREAM	
5	1 EA	127386-2	A2	LNB, SMW, DUAL TRI/QUAD L.O., KU BAND	
6	1 EA	125411-3	G	DAC-2202, SCPC RCVR, 9 WIRE IF	(NOT SHOWN)
7	1 EA	123752-5	D	BELOW DECK KIT, L-BAND, PED & RF M&C	(NOT SHOWN)
9	1 EA	121711	A	BALANCE WEIGHT KIT	(NOT SHOWN)
10	1 EA	129300		CUSTOMER DOC PACKET, 2406-51	(NOT SHOWN)
11	1 EA	123324-2	A	SHIP STOWAGE KIT, XX04 & XX03 & 24XX	(NOT SHOWN)

				
<b>SYSTEM, 2406-51, 8 WATT, QUAD</b>				
PROD FAMILY SERIES 06	EFF. DATE 28-Jan-09	SHT 1 OF 1	DRAWING NUMBER <b>129293-2</b>	REV <b>A</b>

REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
A	N/A	1-08-09	RELEASED TO PRODUCTION, WAS X1.	K.D.H.



DASH	BAND	POL	WATTS	RF MFR	LNB	OTHER
-1	KU	LIN	8 W	WAVESTREAM BUC	QUAD	-
-2	KU	LIN	8W	WAVESTREAM BUC	NO LNB	

**REFERENCE DRAWINGS:**  
 129296 SYSTEM BLOCK DIAGRAM.  
 129297 ANTENNA SYSTEM SCHEMATIC.  
 124348 PEDESTAL SCHEMATIC.  
 122663 INSTALLATION ARRANGEMENT.

**NOTES: UNLESS OTHERWISE SPECIFIED**  
 1. RADOME TOP IS NOT SHOWN FOR CLARITY.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994		DRAWN BY: K.D.H.		<b>Sea Tel</b> <i>COBHAM</i> Tel. 925-798-7979 Fax. 925-798-7986	
MATERIAL: N/A		DRAWN DATE: 11-5-08			
FINISH: N/A		APPROVED BY:		TITLE: SYSTEM, 2406-51	
SIZE: B		APPROVED DATE:		DRAWING NUMBER: 129293	
SCALE: NONE		FIRST USED: 2406-51		REV: A	
3rd ANGLE PROJECTION		SHEET NUMBER		1 OF 1	

## SINGLE LEVEL MFG BILL OF MATERIAL

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	129295-1	A	GENERAL ASS'Y, 2406-51	
2	1 EA	125808-1	B	RADOME ASS'Y, 24XX GA INSTALL, 34 IN	
3	1 EA	129298-3	A1	FEED ASS'Y, CROSS POL, W/COAX RJ, 24	
5	1 EA	126745-1	A2	BUC, KU-BAND, 25W, WAVESTREAM	
6	1 EA	127396-1	A	POWER SUPPLY, 48 VDC, WAVESTREAM	
7	1 EA	127386-2	A2	LNB, SMW, DUAL TRI/QUAD L.O., KU BAND	
8	1 EA	124311-65	C	CABLE ASS'Y, AC POWER	
9	1 EA	127415-1	A	HARNESS ASS'Y, M & C, ADD-ON,WAVEST	
10	1 EA	127502-4	A	CABLE ASS'Y, SHIELDED INTERCONNECT	
11	1 EA	117611-3	H	MODEM ASS'Y, PEDESTAL, 3 CH, 50 OHM	
12	1 EA	117168-1	P	MODEM ASS'Y, PEDESTAL, 3 CH, 75 OHM	
15	1 EA	115708-1	L	CIRCUIT BREAKER BOX ASS'Y, 220V	
16	1 EA	125570-2	E1	POWER SUPPLY ASS'Y, COSEL 150W, RH	
17	1 EA	121185-4	J1	PCU ENCLOSURE ASS'Y, 3-AXIS, (2403, 24	
18	1 EA	116024-5	J3	SHIELDED POLANG RELAY ASS'Y	
19	1 EA	122208-3	L	LEVEL CAGE ASS'Y, SIDE EXIT, 080 P. 90	
20	1 EA	116708	H	HALL EFFECT ENCLOSURE ASS'Y	
21	1 EA	121966	D1	GPS ANTENNA, RETERMINATED, 90.0 L	
22	1 EA	124999-5	B2	HYBRID POWER RING ASS'Y, HIGH POWE	
23	1 EA	124288-24	F	CABLE ASS'Y, AC POWER, 24 IN	
25	1 EA	121425-5	D4	HARNESS ASS'Y, INTERFACE, 2406	
26	1 EA	124213-3	D	HARNESS ASS'Y, 3BLDC, 2406	
27	1 EA	122223-4	E3	HARNESS ASS'Y, PEDESTAL, REFERENC	
28	1 EA	121485-1	F	HARNESS ASS'Y, REFLECTOR	
30	1 EA	126797-12		CABLE ASS'Y, ST-18, SMA(M) - SMA(M), 12	
31	1 EA	127963-30YEL	A	CABLE ASS'Y, RG-179 COAX, F TO F(RA), 3	
32	1 EA	123758-6	B	CABLE ASS'Y, SMA(M)-N(M) 90 DEG, 6 FT	
33	1 EA	113303-4	S	CABLE ASS'Y, SMA 90 - SMA (M), 72 IN	
34	1 EA	113303-9	S	CABLE ASS'Y, SMA 90 - SMA (M), 17 3/8 IN	




### SYSTEM BLOCK DIAGRAM, 2406-51


PROD FAMILY LIT	EFF. DATE 28-Jan-09	SHT 1 OF 2	DRAWING NUMBER 129296-1	REV A
--------------------	------------------------	------------	----------------------------	----------

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
35	2 EA	114972-4	L	CABLE ASS'Y, SMA(M) - SMA(M), 30 IN	
38	1 EA	115492-13	C1	ADAPTER, SMA(M)-SMA(F), 90 DEGREE	
39	2 EA	115492-1	C1	ADAPTER, N(F)-SMA(F), W/FLANGE	
40	1 EA	126878-1	A	WAVEGUIDE FILTER, WR-75, 180 DEG E-B	
41	1 EA	114280-13	E8	WAVEGUIDE, WR-75, 90 DEG H-BEND, 4.0 I	
42	1 EA	114280-3	E8	WAVEGUIDE, WR-75, 90 DEG H-BEND, 1 IN	
43	1 EA	110496-9	H	WAVEGUIDE ADAPTER, WR-75 TO SMA, T	
44	1 EA	126756-1	X1	WAVEGUIDE ADAPTER, WR-62 TO SMA, R	
100	1 EA	125411-3	G	DAC-2202, SCPC RCVR, 9 WIRE IF	
101	1 EA	116881-16	C	MUX RACK PANEL ASS'Y, RX SS, SF, TX (	
102	1 EA	121628-4	P	TERMINAL MOUNTING STRIP ASS'Y, ACU	
103	1 EA	117168-2	P	MODEM ASS'Y, BASE, 3 CH, 75 OHM	
104	1 EA	117611-4	H	MODEM ASS'Y, BASE, 3 CH, 50 OHM	
105	1 EA	116298-6	F4	HARNESS ASS'Y, ACU TO MUX/TERM TO	
106	1 EA	120643-25	A	CABLE ASS'Y, RS232, 9-WIRE, STRAIGHT,	
107	1 EA	119479-10	B	CABLE ASS'Y, CAT5 JUMPER, 10 FT.	
110	1 EA	113303-10	S	CABLE ASS'Y, SMA 90 - SMA (M), 8 IN	
111	1 EA	114972-9	L	CABLE ASS'Y, SMA(M) - SMA(M), 6 IN	
112	2 EA	111115-6	B	CABLE ASS'Y, F(M)-F(M), 6 FT.	
113	1 EA	116700-6	F	CABLE ASS'Y, RG223, N(M)-F(M), 6 FT.	
114	1 EA	114973-72	D	CABLE ASS'Y, N(M)-N(M), 72 IN.	
120	1 EA	115492-1	C1	ADAPTER, N(F)-SMA(F), W/FLANGE	
121	1 EA	110567-19		ADAPTER, N(F)-N(F), STRAIGHT, FLANGE	

				
<b>SYSTEM BLOCK DIAGRAM, 2406-51</b>				
PROD FAMILY LIT	EFF. DATE 28-Jan-09	SHT 2 OF 2	DRAWING NUMBER <b>129296-1</b>	REV <b>A</b>

REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
A	N/A	12-9-08	RELEASED TO PRODUCTION WAS REV. X1; ITEMS 42 & 38 ADDED	MSF




REFERENCE DRAWINGS:  
 129297 ANTENNA SYSTEM SCHEMATIC  
 122182 ANTENNA PEDESTAL SCHEMATIC

NOTES: UNLESS OTHERWISE SPECIFIED:  
 1. FOR SYSTEMS WITH A 50-OHM SATELLITE MODEM (HAVING N-TYPE CONNECTORS):  
 A. REMOVE N-F CABLE ASS'Y (ITEM 113) FROM THE SATELLITE MODEM TX PATH AND SUBSTITUTE N-N CABLE ASS'Y (ITEM 114).  
 B. REMOVE F-F CABLE ASS'Y (ITEM 112) FROM THE SATELLITE MODEM RX PATH AND SUBSTITUTE PREVIOUSLY REMOVED N-F CABLE ASS'Y (ITEM 113).

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5°	DRAWN BY: MSF		<b>Sea Tel</b> <i>COBHAM</i> Tel. 925-798-7979 Fax. 925-798-7986	
	DRAWN DATE: 11-5-08			
INTERPRET TOLERANCING PER ASME Y14.5M - 1994	APPROVED BY:			TITLE: SYSTEM BLOCK DIAGRAM,
MATERIAL:	APPROVED DATE:			2406-51
FINISH:	SIZE: B	SCALE:	DRAWING NUMBER: 129296	
3rd ANGLE PROJECTION	FIRST USED:	2406-51	SHEET NUMBER: 1 OF 1	


**SINGLE LEVEL MFG BILL OF MATERIAL**


FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	127005-2	B3	PEDESTAL ASS'Y, 2406, EMI	
2	1 EA	129299-3	A	ANTENNA ASS'Y, OPTIM 24 IN, TX/RX, W/C	
3	1 EA	127358-1	A1	EQUIPMENT FRAME ASS'Y, WAVESTREA	
4	1 EA	110496-9	H	WAVEGUIDE ADAPTER, WR-75 TO SMA, T	
5	1 EA	114280-13	E8	WAVEGUIDE, WR-75, 90 DEG H-BEND, 4.0 I	
6	1 EA	114280-3	E8	WAVEGUIDE, WR-75, 90 DEG H-BEND, 1 IN	
7	2.5 IN	124077-4	A1	TAPE, 3M VHB #4952, SYNTHETIC ADHESI	
8	1 EA	126797-12		CABLE ASS'Y, ST-18, SMA(M) - SMA(M), 12	
10	1 EA	121966	D1	GPS ANTENNA, RETERMINATED, 90.0 L	
11	4 EA	127278-1	A	BRACKET, EL CLIP, XX06	
12	1 EA	127617-1	A	LABELS INSTALLATION, 2406	
15	1 EA	115492-12		ADAPTER, SMA(M)-SMA(F)	
19	1 EA	127415-1	A	HARNESS ASS'Y, M & C, ADD-ON,WAVEST	(NOT SHOWN)
20	1 EA	127963-30YEL	A	CABLE ASS'Y, RG-179 COAX, F TO F(RA), 3	(NOT SHOWN)
21	1 EA	123758-6	B	CABLE ASS'Y, SMA(M)-N(M) 90 DEG, 6 FT	(NOT SHOWN)
22	1 EA	124311-65	C	CABLE ASS'Y, AC POWER	(NOT SHOWN)
23	1 EA	121485-1	F	HARNESS ASS'Y, REFLECTOR	(NOT SHOWN)
24	1 EA	121425-5	D4	HARNESS ASS'Y, INTERFACE, 2406	(NOT SHOWN)
25	1 EA	122223-4	E3	HARNESS ASS'Y, PEDESTAL, REFERENC	(NOT SHOWN)
26	1 EA	124213-3	D	HARNESS ASS'Y, 3BLDC, 2406	(NOT SHOWN)
27	1 EA	113303-9	S	CABLE ASS'Y, SMA 90 - SMA (M), 17 3/8 IN	(NOT SHOWN)
28	1 EA	113303-4	S	CABLE ASS'Y, SMA 90 - SMA (M), 72 IN	(NOT SHOWN)
29	1 EA	124288-24	F	CABLE ASS'Y, AC POWER, 24 IN	(NOT SHOWN)
33	1 EA	117585-7	A1	TERMINAL BLOCK, 4-POLE, 10-AWG	
34	3 EA	126293-1	A	HARDWARE KIT, D-SUB INSTALL	
35	1 EA	127431-1	D	GROUND BONDING KIT, 2406-XX	(NOT SHOWN)
45	1 EA	126537	A	COUNTER WEIGHT ASS'Y	
46	1 EA	115420-2	F	TRIM WEIGHT, 10 X 3 X 3/8 IN	
47	1 EA	115420-3	F	TRIM WEIGHT, 10 X 3 X 1/4 IN	

				
<b>GENERAL ASS'Y, 2406-51</b>				
PROD FAMILY SERIES 06	EFF. DATE 28-Jan-09	SHT 1 OF 2	DRAWING NUMBER <b>129295-1</b>	REV <b>A</b>


**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
48	9 EA	108519-4	E	WEIGHT, TRIM 7.0 OZ, BLUE	
49	5 EA	127289-2		NUT, 13/16 UNISTRUT, 1/4-20, W/SPRING,	
53	1 EA	118294-12	B1	HARDWARE KIT, WR-75 FLANGE, BLIND	
54	2 EA	118294-1	A3	HARDWARE KIT, WR-75 FLANGE, 6-32, 1/2	
56	2 EA	114593-149		SCREW, SOCKET HD, 8-32 x 7/8, S.S.	
57	2 EA	114580-009		WASHER, FLAT, #8, S.S.	
71	2 EA	114586-553		SCREW, HEX HD, 1/4-20 x 5, S.S.	
72	27 EA	114580-029		WASHER, FLAT, 1/4, S.S.	
73	7 EA	114583-029		NUT, HEX, 1/4-20, S.S.	
74	1 EA	114586-535		SCREW, HEX HD, 1/4-20 x 1/2, S.S.	
75	8 EA	114586-536		SCREW, HEX HD, 1/4-20 x 5/8, S.S.	
76	8 EA	114581-029		WASHER, LOCK, 1/4, S.S	
77	1 EA	114586-548		SCREW, HEX HD, 1/4-20 x 3-1/4, S.S.	
78	2 EA	114586-538		SCREW, HEX HD, 1/4-20 x 1, S.S.	
79	4 EA	114593-204		SCREW, SOCKET HD, 1/4-20 x 1/2, S.S.	
80	4 EA	114580-027		WASHER, FLAT, 1/4, SMALL PATTERN, S.S	
81	2 EA	114586-556		SCREW, HEX HD, 1/4-20 x 7/8, S.S.	
82	2 EA	114586-543		SCREW, HEX HD, 1/4-20 x 2, S.S.	

				
<b>GENERAL ASS'Y, 2406-51</b>				
PROD FAMILY SERIES 06	EFF. DATE 28-Jan-09	SHT 2 OF 2	DRAWING NUMBER <b>129295-1</b>	REV <b>A</b>



REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
X2	N/A	11-7-08	NEW DRAWING	K.D.H.




**REFERENCE DRAWINGS:**  
 129296 SYSTEM BLOCK DIAGRAM.  
 129297 ANTENNA SYSTEM SCHEMATIC.  
 124348 PEDESTAL SCHEMATIC.


**NOTES: UNLESS OTHERWISE SPECIFIED**  
 1. APPLY ADHESIVE PER SEATEL SPEC. 121730.  
 2. TORQUE THREADED FASTENERS PER SEATEL SPEC. 122305.  
 3. ROUTE ALL HARNESS AND CABLES ASSEMBLIES PER SEATEL SPEC. 121872.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994		DRAWN BY: K.D.H.		<b>Sea Tel</b> <i>COBHAM</i> Tel. 925-798-7979 Fax. 925-798-7986	
MATERIAL: N/A		DRAWN DATE: 11-5-08			
FINISH: N/A		APPROVED BY:		TITLE: <b>GENERAL ASS'Y</b> <b>2406-51</b>	
SIZE: B		SCALE: NONE		APPROVED DATE:	
FIRST USED: 2406-51		DRAWING NUMBER: 129295		REV: A	
3rd ANGLE PROJECTION		SHEET NUMBER: 1 OF 2			

**POWER SUPPLY & SSPB SHOWN FOR REFERENCE ONLY**



SIZE	SCALE:	DRAWING NUMBER	REV
B	NONE	129295	A
		SHEET NUMBER	2 OF 2



**NOTES:**  
 1 REFER TO DRAWING 124348 SCHEMATIC, PEDESTAL XX06 FOR CONNECTION DETAILS

**REFERENCE DRAWINGS:**  
 121425 INTERFACE HARNESS ASSEMBLY / SCHEMATIC  
 116280 SHIELDED POLANG AUX RELAY PCB SCHEMATIC  
 129296 SYSTEM BLOCK DIAGRAM  
 129293 SYSTEM 2406-S1  
 124348 PEDESTAL SCHEMATIC


<b>SeaTel, Inc.</b> CONCORD, CA		
SCALE: NONE	APPROVED BY:	DRAWN BY: MSF
DATE: 11-6-08		DRAWING SIZE: C
<b>SCHEMATIC, ANTENNA SYSTEM</b>		
MODEL: 2406-S1	SHT 1 OF 1	DRAWING NUMBER: 129297
		REV: A

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	122137	B	REFLECTOR MACHINING, 24 IN	
2	1 EA	122997	A	(SEE COMMENT) VERTEX FEED, 24 IN., 24	
3	1 EA	126496-2	B2	FEED ASS'Y, KU-BAND, CROSS POL, WO/	
4	2 EA	124160	C	BRACKET, REFLECTOR	
50	4 EA	114583-005		NUT, HEX, 4-40, S.S.	
51	4 EA	114581-005		WASHER, LOCK, #4, S.S.	
52	4 EA	114580-006		WASHER, FLAT, #4, SMALL PATTERN, S.S.	
60	4 EA	119961-007		NUT, HEX, SMALL PATTERN, 6-32, S.S.	
61	4 EA	114581-007		WASHER, LOCK, #6, S.S.	
62	4 EA	114580-008		WASHER, FLAT, #6, SMALL PATTERN, S.S.	
70	4 EA	114588-829		SCREW, PAN HD, PHIL, 10-32 x 1/2, S.S.	
71	12 EA	114580-011		WASHER, FLAT, #10, S.S.	
72	6 EA	114583-011	A	NUT, HEX, 10-32, S.S.	
73	2 EA	114588-831		SCREW, PAN HD, PHIL, 10-32 x 3/4, S.S.	

				
<b>ANTENNA ASS'Y, OPTIM 24 IN, TX/RX, W/O ROTARY JOINT</b>				
PROD FAMILY COMMON	EFF. DATE 28-Jan-09	SHT 1 OF 1	DRAWING NUMBER <b>124226-2</b>	REV <b>E</b>

REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
A	5546	4-17-07	ITEM 50 WS ITEM 6; ADDED ITEMS 7, 52, 60, & 62; ADDED -2; REV WS X1	SMS
B	5777	8-20-07	-2 ONLY; ITEM 3 WS 126496	SMS
C	5831	9-27-07	-2 ONLY; ADDED ITEMS 4, 70, 71, & 72; ITEM 62 WS 114580-007	SMS
D	5920	11-09-07	ITEM 70 WS QTY 6; ADDED ITEM 73	KDH
D1	N/A	11-15-07	CORRECTED VIEW ERRORS	
D2	N/A	12-19-07	ON -1: ITEMS 5 & 7 DELETED; ITEMS 4, & 70-73 ADDED. ON -2: ITEMS 5 & 7 DELETED.	RJW
E	6063	02-11-08	ADDED ITEMS 51 & 61	HT




- NOTES: UNLESS OTHERWISE SPECIFIED**
1. APPLY ADHESIVE PER SEATEL SPEC. 121730.
  2. TORQUE THREADED FASTENERS PER SEATEL SPEC. 122305.

DASH	DESCRIPTION
-1	W/ROTARY JOINT
-2	W/OROTARY JOINT

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994		DRAWN BY: <b>ALVARO</b>		 4030 NELSON AVENUE CONCORD, CA 94520 Tel. 925-798-7979 Fax. 925-798-7986	
MATERIAL: N/A		DRAWN DATE: <b>04-08-05</b>			
FINISH: N/A		APPROVED BY:		TITLE: <b>ANTENNA ASS'Y OPTIM 24 IN, TX/RX</b>	
3rd ANGLE PROJECTION		SIZE: <b>B</b>	SCALE: <b>1:2</b>	DRAWING NUMBER: <b>124226</b>	REV: <b>E</b>
FIRST USED: 2403-22				SHEET NUMBER 1 OF 2	

**DASH -1 SHOWN**






SIZE	SCALE:	DRAWING NUMBER	REV
B	1:2	124226	E
		SHEET NUMBER	2 OF 2

**SINGLE LEVEL MFG BILL OF MATERIAL**


FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	125176	A	RADOME TOP FAB, 34 INCH, 90 DEG LIP	
2	1 EA	127057	A	RADOME BASE FAB, 34 INCH, DURO	
4	1 EA	118576	C	MOUNTING KIT, PEDESTAL	NOT SHOWN
6	10 EA	119801-019	B	CABLE TIE, NYLON, 7.5 IN, NATURAL	
7	1 EA	111679-5	0	CABLE CLAMP, NYLON, .375 DIA, #8 MTG	
8	2 EA	111679-7	0	CABLE CLAMP, NYLON, .50 DIA, #8 MTG H	
9	1 EA	111679-25	0	CABLE CLAMP, NYLON, 3/4 DIA, #10 MTG	
10	1 OZ	125948-1	A	ADHESIVE, HOT MELT, 3M SCOTCH-WELD	NOT SHOWN
11	2 EA	110481-4	F	DECAL, LOGO, SEA TEL, 16 X 6.3 IN	
16	1 EA	123549	F	KIT, RADOME HARDWARE MOUNTING	
50	2 EA	114588-190		SCREW, PAN HD, PHIL, 8-32 x 1/4, S.S.	
53	4 EA	114588-191		SCREW, PAN HD, PHIL, 8-32 x 5/16, S.S.	
54	6 EA	114580-009		WASHER, FLAT, #8, S.S.	
60	3 EA	114588-198		SCREW, PAN HD, PHIL, 8-32 x 7/8, S.S.	
61	3 EA	114580-009		WASHER, FLAT, #8, S.S.	
64	9 EA	125806-1	A	ROTALOC HEX NUT, BONDING, F1-B38-8-3	


				
<b>RADOME ASS'Y, 24XX GA INSTALL, 34 IN</b>				
PROD FAMILY COMMON	EFF. DATE 28-Jan-09	SHT 1 OF 1	DRAWING NUMBER <b>125808-1</b>	REV <b>B</b>

REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
A2	5823	09-25-07	ITEM 2 WS 125177. REMOVE DETAIL 'C'.	SL
A3	5849	10-16-07	ADDED GND WIRE TO SHT 2; DELETED ITEMS 56-58	RJW
B	6286	06-26-08	MOVE THE CIRCUIT BREAKER BOX & CONNECTOR BRACKET & ROATOCS	SL
"	"	"	COUNTERCLOCKWISE ONE SECTION OVER. UPDAT NOTES PER RED LINES.	SL




- NOTES: UNLESS OTHERWISE SPECIFIED
- 1 PLACE BOW MARKER AT LOCATION SHOWN, ON INSIDE OF DOME.
  - 2 POSITION DECALS AS SHOWN, CENTERED AT BOTH PORT AND STARBOARD. DECALS MUST BE PARALLEL TO RADOME FLANGE WITHIN .13 INCH MEASURED FROM THE BOTTOM OF THE 2 LETTER E's ON SEATEL DECAL.
  - 3. APPLY ADHESIVE PER SEATEL SPEC. 121730.
  - 4 BAG & ATTACH RADOME MOUNTING KIT, ITEM 16, TO P-CLAMP.
  - 5 TO ATTACH BONDING NUTS: CLEAN FIBERGLASS WITH SIMPLE GREEN & ACETONE AT LOCATIONS SHOWN; APPLY ADHESIVE (125948) TO FIBERGLASS; PRESS-IN BONDING NUTS; AND ALLOW TO SET.



TOLERANCES UNLESS OTHERWISE SPECIFIED		DRAWN BY: SL		 4030 NELSON AVENUE CONCORD, CA 94520 Tel. 925-798-7979 Fax. 925-798-7986	
X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994		DRAWN DATE: 9-7-06			
MATERIAL: N/A		APPROVED BY:		TITLE: RADOME ASSEMBLY	
FINISH: N/A		APPROVED DATE:		24XX GA INSTALL, 34 IN	
3rd ANGLE PROJECTION		SIZE: B	SCALE: 1:8	DRAWING NUMBER: 125808	REV: B
FIRST USED: 2406-7				SHEET NUMBER: 1 OF 2	



SIZE B	SCALE: 1:4	DRAWING NUMBER: 125808	REV: B
SHEET NUMBER:		2 OF 2	



REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
B1	N/A	4-25-05	CHANGED MOUNTING KIT P/N FROM 118569 TO 123549 ON NOTES 2 & 3.	AEF
B2	N/A	6-1-05	DIMENSIONS VERIFIED AND CORRECTED TO CURRENT BUILD.	L.R.
B3	N/A	11/18/05	DETAIL FOR EYE NUT INSTALL. REDRAWN TO SHOW MORE REDOME REFERENCE OUTLINE.	AEF
B4	N/A	9-8-06	ADD 50 INCH READOME. NOTE "LOCATE HATCH & CABLE GROMMETS DIRCTLY AFT	SL
"	"	"	(EXCEPT 34") " WS "LOCATE HATCH (48"& 60" ONLY) & CABLE GROMMETS DIRECTLY AFT."	SL



**EYE NUT INSTALLATION**

IF NEEDED FOR LIFTING, INSTALL 4X EYE NUTS. (PART OF RADOME KIT P/N: 123549) EQUALLY SPACED.

**NOTES: UNLESS OTHERWISE SPECIFIED**

1 INDICATED ITEMS ARE PART OF MOUNTING KIT P/N: 123549

2 APPLY ADHESIVE PER SEATEL SPEC. 121730. LOCTITE 271 (RED) PROVIDED WITH MOUNTING KIT, P/N 123549

3 MINIMUM DIAMETER OF MAST MOUNTNG PLATE EQUAL TO RADOME BASE DIAMETER.

**REFERENCE DRAWINGS**

122356 RADOME ASS'Y, 60"  
 122353 RADOME ASS'Y, 48"  
 122350 RADOME ASS'Y, 40"  
 122326 RADOME ASS'Y, 34"

TOLERANCES UNLESS OTHERWISE SPECIFIED X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994	DRAWN BY: P. McCANN		 4030 NELSON AVENUE CONCORD, CA 94520 Tel. 925-798-7979 Fax. 925-798-7986	
	DRAWN DATE: 3-4-04			
MATERIAL: --	APPROVED BY:		TITLE: RADOME INSTALLATION	
FINISH: --	SIZE: B	SCALE: 1/15	DRAWING NUMBER: 122663	
3rd ANGLE PROJECTION		FIRST USED: --	SHEET NUMBER: 1 of 1	

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	127425-1	A	BELT KIT, 2406	
2	1 EA	121185-4	J1	PCU ENCLOSURE ASS'Y, 3-AXIS, 2403	
3	1 EA	116024-5	J2	SHIELDED POLANG RELAY ASS'Y	
4	1 EA	122937-2	F1	LEVEL CAGE ASS'Y, BOTTOM EXIT, 90 DE	
5	1 EA	121951	D1	MOTOR, SIZE 23, DOUBLE STACK/W ENC	AZ
6	1 EA	108944-3	K1	PULLEY, TIMING, 10T	AZ
7	1 EA	114590-188		SCREW, SOCKET SET-CUP, 8-32 x 1/8, S.S.	AZ
8	1 EA	116139-2	J3	MOTOR, SIZE 23, BLDC, 9 PIN	CL/EL
9	1 EA	114079-2	0	PULLEY, 1/5P 10T, 2FLG	CL/EL
10	1 EA	114590-824		SCREW, SOCKET SET-CUP, 10-32 x 3/16, S	CL/EL
11	1 EA	115425-2	J3	POT ASS'Y (ELEX.), POLANG	
12	1 EA	117139	C	GEAR, MOD., SPUR	
13	4 EA	114590-824		SCREW, SOCKET SET-CUP, 10-32 x 3/16, S	POT & MTR
14	1 EA	126986-1	A	MOTOR, DC GEAR, W/POLANG ADAPTER	
15	1 EA	127047-1	A	GEAR, MOD., SPUR	

				
<b>SPARE PARTS KIT, 2406, STANDARD</b>				
PROD FAMILY COMMON	EFF. DATE 07-Dec-07	SHT 1 OF 1	DRAWING NUMBER <b>127421-1</b>	REV <b>A</b>

**SINGLE LEVEL MFG BILL OF MATERIAL**


<b>FIND</b>	<b>QTY</b>	<b>PART NO</b>	<b>REV</b>	<b>DESCRIPTION</b>	<b>REFERENCE DESIGNATOR</b>
1	1 EA	127421-1	A	SPARE PARTS KIT, 2406, STANDARD	
2	1 EA	117168-2	L1	MODEM ASS'Y, BASE, 3-CH. 75 OHM	
3	1 EA	117168-1	L1	MODEM ASS'Y, PEDESTAL, 3-CH. 75 OHM	
4	1 EA	125570-2	D1	POWER SUPPLY ASS'Y, COSEL 150W, RH	
5	1 EA	114789-810		TRANSPORT CONTAINER	

				
<b>SPARE PARTS KIT, 2406, PREMIUM</b>				
PROD FAMILY COMMON	EFF. DATE 07-Dec-07	SHT 1 OF 1	DRAWING NUMBER <b>127422-1</b>	REV <b>A</b>

**SINGLE LEVEL MFG BILL OF MATERIAL**

<b>FIND</b>	<b>QTY</b>	<b>PART NO</b>	<b>REV</b>	<b>DESCRIPTION</b>	<b>REFERENCE DESIGNATOR</b>
1	1 EA	127422-1	A	SPARE PARTS KIT, 2406, PREMIUM	
2	1 EA	121250-1	C3	POWER RING ASS'Y, 66 IN. CONTACT WIR	
3	1 EA	124068-1	A1	ROTARY JOINT, COAXIAL, DUAL CHANNE	
4	1 EA	121966	D	GPS ANTENNA, RETERMINATED, 90.0 L	

				
<b>SPARE PARTS KIT, 2406, MASTER</b>				
PROD FAMILY COMMON	EFF. DATE 07-Dec-07	SHT 1 OF 1	DRAWING NUMBER <b>127423-1</b>	REV <b>A</b>



REVISION HISTORY

REV	ECO#	DATE	DESCRIPTION	BY
B	5319	5-29-06	NOTE 2 ADDED	MSF
B1	N/A	1-19-07	NOTE 2 UPDATED; NOTE 3 ADDED	MSF
B2	N/A	11-12-07	ADDED PEDESTAL HARNESS, 3 BLDC P/N 124213-3 (2406).	MSF
B3	N/A	11-12-07	PIN 4 WAS PIN 3 ON BRAKE HARNESS P/N 125726-1.	MSF

NOTES: UNLESS OTHERWISE SPECIFIED

- FOR WIRE LENGTHS AND ASSEMBLY DETAILS. SEE PEDESTAL HARNESS ASSEMBLY.
- BRAKE NOT CURRENTLY AVAILABLE ON ALL XX06 MODELS.
- BLDC MOTOR P/N 116138-2  
BLDC MOTOR W/BRAKES P/N 1125644-1

REFERENCE DRAWINGS:


- 121172 PCB SCHEMATIC, 3-AXIS PCU
- 120851 SCHEMATIC, MOTOR DRIVER 3BLDC

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. <48" = ± 1" <15' = ± 2" <100' = ± 4" >100' = ± 6"	DRAWN BY: JWM		 4030 NELSON AVENUE CONCORD, CA 94520 Tel. 925-798-7979 Fax. 925-798-7986	
	DRAWN DATE: 2-15-05			
INTERPRET TOLERANCING PER ASME Y14.5M - 1994	APPROVED BY:		TITLE: SCHEMATIC, PEDESTAL XX06, UNLIMITED AZ	
MATERIAL:	APPROVED DATE:		DRAWING NUMBER: 124348	
FINISH:	SIZE: B	SCALE:	DRAWING NUMBER: 124348	REV: B3
3rd ANGLE PROJECTION		FIRST USED:	SHEET NUMBER: 1 OF 1	

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	112657	D	MACHINING, TERMINAL MOUNTING STRIP	
2	1 EA	126865-2	E	PCB ASS'Y, TERMINAL MOUNTING STRIP,	
3	1 EA	112936-36	D1	CABLE ASS'Y, D-SDB, 25 PIN, 36 IN	
5	1 EA	116669-36	B1	CABLE ASS'Y, D-SUB, 9-PIN, 36 IN.	
7	2 EA	121228-3072		STANDOFF, HEX, F/F, 6-32 X .25 OD X .50,	
9	2 EA	114588-146		SCREW, PAN HD, PHIL, 6-32 x 3/8, S.S.	
11	8 EA	114588-107		SCREW, PAN HD, PHIL, 4-40 x 5/16, S.S.	
19	2 EA	114588-144		SCREW, PAN HD, PHIL, 6-32 x 1/4, S.S.	
29	1 EA	119478-5	C3	CABLE ASS'Y, RJ-45 SERIAL, 60 IN.	
30	1 EA	126877	B1	HARNESS ASS'Y, COMTECH MODEM INTE	

				
<b>TERMINAL MOUNTING STRIP ASS'Y, ACU</b>				
PROD FAMILY COMMON	EFF. DATE 29-Sep-08	SHT 1 OF 1	DRAWING NUMBER <b>121628-4</b>	REV <b>N2</b>



2X (19)

2X (9)

(7) 2X

(1)

(3)

(2)

(29)

TO DIRECT  
CONSOLE  
PORT

4X (11)

(11) 4X

(3)

(5)


- NOTES (UNLESS OTHERWISE SPECIFIED):
1. APPLY ADHESIVE PER SEATEL SPEC. 121730
  2. BAG ITEM 30 AND SHIP WITH PANNEL

**-4 SHOWN**


SIZE	SCALE:	DRAWING NUMBER:	REV:
B	1/2	121628	N2
SHEET NUMBER:			3 of 4

**SINGLE LEVEL MFG BILL OF MATERIAL**

FIND	QTY	PART NO	REV	DESCRIPTION	REFERENCE DESIGNATOR
1	1 EA	116880	F	PANEL MACHINING, RACK, BASE MUX	
2	1 EA	117168-2	P	MODEM ASS'Y, BASE, 3 CH, 75 OHM	
3	1 EA	116388	D	BRACKET, CONNECTOR	
4	1 EA	115492-1	C1	ADAPTER, N(F)-SMA(F), W/FLANGE	
5	8 EA	114588-107		SCREW, PAN HD, PHIL, 4-40 x 5/16, S.S.	
6	8 EA	114583-005		NUT, HEX, 4-40, S.S.	
7	2 EA	114588-144		SCREW, PAN HD, PHIL, 6-32 x 1/4, S.S.	
8	6 EA	114580-007		WASHER, FLAT, #6, S.S.	
9	1 EA	110567-19		ADAPTER, N(F)-N(F), STRAIGHT, FLANGE	
10	1 EA	110567-11		ADAPTER, N(M)-F(F), STRAIGHT	
11	1 EA	113303-10	S	CABLE ASS'Y, SMA 90 - SMA (M), 8 IN	
12	8 EA	114580-005		WASHER, FLAT, #4, S.S.	
13	4 EA	114588-145		SCREW, PAN HD, PHIL, 6-32 x 5/16, S.S.	

				
<b>BASE MUX RACK PANEL ASS'Y</b>				
PROD FAMILY COMMON	EFF. DATE 28-Jan-09	SHT 1 OF 1	DRAWING NUMBER <b>116881-3</b>	REV <b>K</b>

REVISION HISTORY				
REV	ECO#	DATE	DESCRIPTION	BY
H	5003	9-21-05	EDIT NOTE. QTY IN ITEM 8 WS 6. REMOVE BOM IN DRAWING.	SL
"	"	"	SPLIT ALL DASH TO INDIVIDUAL PAGE , SEE -1 FOR REV DETAIL.	"
J	5678	6-27-07	ADDED ITEMS 12 AND 13, ITEM 5 WAS P/N 114588-106,	SMS
"	"	"	ITEM 7 WAS QTY 6, ITEM 8 WAS QTY 2	"
K	6483	12-15-08	ADDED NOTE 3, CORRECT ERRORS AND UPDATE DRAWING TO MATCH THE BOM.	HT



- NOTES:**
- 1. APPLY ADHESIVE PER SEA TEL SPEC. 121730
  - 2. IDENTIFY PER SEA TEL SPEC. 122930 APPROXIMATELY WHERE SHOWN.
  - 3. IF ITEM 10 IS NOT REQUIRED IN BELOW DECK KIT, PLACE IN BAG, MARK PER SEATEL SPEC 122930 AND SHIP WITH UNIT.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. X.X = ±.050 X.XX = ±.020 X.XXX = ±.005 ANGLES: ±.5° INTERPRET TOLERANCING PER ASME Y14.5M - 1994	DRAWN BY: MAB		<b>Sea Tel</b> <small>COBHAM</small> Tel. 925-798-7979 Fax. 925-798-7986	
	DRAWN DATE: 5-14-99			
	APPROVED BY:		TITLE: BASE MUX RACK PANEL ASSEMBLY	
	APPROVED DATE:		DRAWING NUMBER: 116881-3	
FINISH: N/A	SIZE B	SCALE: 1/2	REV: K	
FIRST USED: XX97 TVRO (SINGLE MUX)		SHEET NUMBER: 1 OF 1		